

Unterstützte Geräte laut Hersteller (Stand 29.01.2012)

Hersteller	Plattform	Modelle
Nokia	Series 30	3210, 3310, 3315, 3320, 3321, 3330, 3350, 3360, 3361, 3390, 3395, 3410, 3510, 3570, 3580, 3585, 3590, 3610, 5110, 5130, 5190, 5210, 5510, 6110, 6150, 6190, 6210, 6250, 6310, 6310i, 6320, 6340, 6340i, 6360, 6370, 6385, 6510, 6590, 7110, 7160, 7190, 8210, 8250, 8310, 8390, 8810, 8850, 8855, 8890, 8910
Nokia	Series 40	110, 111, 110, 111, 113, 112, 1506, 1680 Classic, 2125, 2220 Slide, 2320 Classic, 2323 Classic, 2330 Classic, 2600 Classic, 2605, 2608, 2610, 2626, 2630, 2650, 2660, 2680 Slide, 2690, 2700 Classic, 2710 Navigation Edition, 2720 Fold, 2730 Classic, 2760, 2855, 2865, 3100, 3105, 3108, 3109 Classic, 3110 Classic, 3120 Classic, 3125, 3128, 3152, 3155, 3155i, 3200, 3205, 3208 Classic, 3220, 3300, 3500 Classic, 3510i, 3520, 3555, 3560, 3586, 3586i, 3587, 3587i, 3588i, 3589i, 3595, 3600 Slide, 3606, 3608, 3610 Fold, 3710 Fold, 3720 Classic, 3806, 5000, 5070, 5100, 5130 XpressMusic, 5140, 5140i, 5200, 5220 XpressMusic, 5300, 5310 XpressMusic, 5330 Mobile TV Edition, 5330 XpressMusic, 5610 XpressMusic, 6010, 6011, 6011i, 6012, 6015, 6020, 6021, 6030, 6060, 6061, 6062, 6066, 6070, 6080, 6085, 6086, 6088, 6100, 6101, 6102, 6102i, 6103, 6108, 6111, 6112, 6125, 6126, 6131, 6133, 6136, 6151, 6152, 6155, 6165, 6170, 6175i, 6178i, 6200, 6208 Classic, 6212 Classic, 6215i, 6216 Classic, 6220, 6225, 6230, 6230i, 6233, 6234, 6235, 6245i, 6255, 6260 Slide, 6263, 6265, 6267, 6270, 6275, 6280, 6282, 6288, 6300, 6300i, 6301, 6303 Classic, 6303i Classic, 6315i, 6316s, 6350, 6500 Classic, 6500 Slide, 6555, 6560, 6585, 6600 Fold, 6600 Slide, 6600i Slide, 6610, 6650, 6651, 6700 Classic, 6750 Mural, 6800, 6810, 6820, 6820, 6822, 7020,

		7070 Prism, 7088, 7100 Supernova, 7200, 7210 Supernova, 7210, 7230, 7230, 7250, 7250i, 7260, 7270, 7280, 7310 Supernova, 7360, 7370, 7373, 7380, 7390, 7500 Prism, 7510 Supernova, 7600, 7610 Supernova, 7900 Prism, 8208, 8600 Luna, 8800 Arte, 8800 Sirocco Edition, 8800, 8801, 8910i, Asha 200, Asha 201, Asha 202, Asha 203, Asha 300, Asha 302, Asha 303, Asha 305, Asha 306, Asha 311, C1-01, C1-02, C2-00, C2-01, C2-01.1, C2-02, C2-02.1, C2-05, C2-05.1, C3-00, C3-01, C3-01.5, C3-01m, X2-00, X2-01, X2-02, X2-05, X3, X3-01, X3-02, X3-02.5
Vertu	Series 30	Ascent 2004, Signature 2002
Vertu	Series 40	Ascent M 2006, Ascent Ti, Constellation, Signature 2006, Signature 2008
Mobiado	Series 40	Professional, Executive

Hersteller	Plattform	Modelle
Sony Ericsson	Sony Ericsson classic phones (non-smartphone)	550im, 658c, 901a, C510, C510a, C702a, C702c, C702i, C901, C902, C902c, C903, C903a, C905, C905a, C905c, D750i, K758c, F100i Jalou by Dolce Gabbana, F100i Jalou, F500i, G502, G502c, G705, G705a, G705u, J10, J105a (Naite), J105i (Naite), J108a Cedar, J108i Cedar, J10i2 Elm, J20 Hazel, J20i Hazel, K500c, K500i, K506c, K508c, K508i, K510i, K510c, K530i, K550i, K550c, K600i, K608i, K610i, K618i, V630i, K630i, K660i, K700c, K700i, K750i, K750c, K770i, K790a, K790i, K790c, K800i, K810i, K818c, K850a, K850i, K858c, S302, S500i, S700c, S700i, S710a, T226, T228, T230, T290c, T290i, T300, T302, T310i, T312,

		<p>T610, T618, T630, T650i, T68, T68i, T68ie, T700, T707, T707a, T715, T715a, U100a Yari, U100i Yari, U10a Aino, U10i, V600i, V640i, V800, V802SE, Z800i, W20 Zylo, W200i, W200c, W20i Zylo, W300i, W300c, W350, W350a, W380a, W380i, W395, W508, W518a, W550i, W550c, W580i, W580c, W595, W600a, W600c, W600i, W610i, W610c, W660i, W700i, W700c, W705, W710i, W710c, W715, W760c, W760i, W800i, W800c, W810i, W810c, W830i, W830c, W850i, W880i, W888c, W890i, W900i, W902, W908c, W910i, W980, W995, W995a, Xperia X5 Pureness, Z1010, Z310a, Z310i, Z500a, Z520a, Z520i, Z520c, Z525a, Z530i, Z530c, Z550i, Z550c, Z555a, Z555i, Z558i, Z558c, Z600, Z608, Z610i, Z710i, Z710c, Z750i, Z770i, Z780i</p>
--	--	---

Hersteller	Plattform	Modelle
Nokia	Series 60	<p>3230, 3250, 3600, 3620, 3650, 3660, 500, 5228, 5230, 5230, 5230, 5232, 5233, 5250, 5320 XpressMusic, 5500 Sport, 5530 XpressMusic, 5630 XpressMusic, 5700 XpressMusic, 5730 XpressMusic, 5800 XpressMusic, 603, 6110 Navigator, 6120 Classic, 6121 Classic, 6122 Classic, 6124 Classic, 6210 Navigator, 6220 Classic, 6260, 6290, 6600, 6620, 6630, 6631, 6638, 6650 (smartphone), 6670, 6680, 6681, 6682, 6700 Slide, 6710 Navigator, 6720 Classic, 6730 Classic, 6760 Slide, 6788, 6788i, 6790 Slide, 6790 Surge, 702T, 7610, 7650, 808 Pureview, C5-00, C5-00.1, C5-00.2,</p>

		C5-00.3, C5-01, C5-03, C5-04, C5-05, C5-06, C6-00, C6-01, C7 Astound, C7-00, E50, E5-00, E5-00.2, E51, E52, E55, E55, E60, E6-00, E6-00.1, E61, E61i, E62, E63, E65, E66, E66, E70, E7-00, E71, E71, E71x, E71x, E72, E73 Mode, E75, E90, N70, N71, N72, N73, N75, N76, N77, N78, N79, N80, N8-00, N81, N82, N85, N86, N90, N91, N92, N93, N93i, N95 8GB, N95, N96, N97 mini, N97, N-Gage QD, N-Gage, T7-00, X5-00, X5-01, X5-01.2, X6, X7-00, X7-00.1
Nokia	Series 80	9300, 9300i, 9500
Nokia	Series 90	7700, 7710
Samsung	Series 60	GT-I7110, GT-I8150, INNOV8 (I8510), OMNIA HD, SGH-D700, SGH-D710, SGH-D720, SGH-D728, SGH-D730, SGH-G810, SGH-i400, SGH-i450, SGH-i520, SGH-i550, SGH-i560, SGH-i570, SGH-L870, SGH-Z600
Panasonic	Series 60	X700, X800
Siemens	Series 60	SX1

Hersteller	Plattform	Modelle
Sony Ericsson	UIQ2	P800, P802, P900, P908, P910a, P910c, P910i
Motorola	UIQ2	A1000, A1010, A920, A925
BenQ	UIQ2	P30, P31
Nokia	UIQ2	6708

Hersteller	Plattform	Modelle
Sony Ericsson	UIQ3	G700, G700c, G700i Business Edition, G702, G900, M600i, M608c, P1c, P1i, P990i, W950i, W958c, W960i
Motorola	UIQ3	MotoRizr Z8, Z10

Hersteller	Plattform	Modelle
Acer	Windows Mobile	Acer Windows Mobile, beTouch E100, beTouch E101, beTouch E200, C510, C530, C531, DX650, DX900, F900, M900, n300, n311, n320, n321, neoTouch P300, neoTouch P400, neoTouch S200, NeoTouch, X960
Airis	Windows Mobile	Airis Windows Mobile, T470, T470E, T483, T483L, T610, T620
Alcatel	Windows Mobile	One Touch OT-S988W
Alltel	Windows Mobile	UTStarcom PPC6700
Amoi	Windows Mobile	Amoi Windows Mobile, E70, E72, E75, E76, E78, E850, E860
AnexTEK	Windows Mobile	AnexTEK Windows Mobile, moboDA 3160, moboDA 3360, moboDA 3380, SP310
AnyDATA	Windows Mobile	AnyDATA Windows Mobile, ASP-210C, ASP-318, ASP-500 GA, ASP-500GA, ASP-505 A, ASP-505A, ASP-505C, ASP-518, ASP-535D, ASP-705W, ASP-725
Asus	Windows Mobile	Asus Windows Mobile, Crystal, Halley, Jupiter, Lamborghini ZX1, M530w, M536, M930, Mars II, MyPal A626, MyPal A632, MyPal A636, MyPal A636N, MyPal A639, MyPal A686, MyPal A696, P305, P320, P525, P526, P527, P535, P550, P552w, P560, P565, P735, P750, P835
AT Mobile	Windows Mobile	AT Bear, AT Cobra, AT Eagle, AT Falcon, AT Mobile Windows Mobile, AT Pelican, Bear, Cobra, Eagle, Falcon, Pelican
Athesi	Windows Mobile	RP1000 QVGA, RP1000 VGA
ATT	Windows Mobile	8525, ATT Windows Mobile, Fuze, Tilt
Audiovox	Windows Mobile	6700, Audiovox Windows Mobile, XV6700
Avantgarde Sol Steel	Windows Mobile	Avantgarde Sol Steel

Axia	Windows Mobile	A306, A308, Axia Windows Mobile
Babiken	Windows Mobile	Vefone V1
BenQ	Windows Mobile	BenQ Windows Mobile, E72, P51, T80
Bluebird	Windows Mobile	Pidion BIP-1300 CDMA, Pidion BIP-2000 CDMA, Pidion BIP-5300, Pidion BIP-6000 QWERTY, Pidion BIP-6000, Pidion BM-100, Pidion BM-150R CDMA, Pidion BM-150R GSM, Pidion BM-200, Pidion BM-500 CDMA
Casio	Windows Mobile	Casio Windows Mobile, DT-X30GR-15, DT-X30GR-15C, DT-X30GR-35, DT-X30GR-35C, DT-X30R-15, DT-X30R-35, IT-800RGC-05, IT-800RGC-15, IT-800RGC-35
Cingular	Windows Mobile	2100, 2125, 3125, 8125, 8500, 8525, Cingular Windows Mobile
Cinte	Windows Mobile	A1, A1+, T3238, Verizon Droid X, W71, YotaMAX4G
Claro	Windows Mobile	9100, Claro Windows Mobile
CyberBank	Windows Mobile	POZ X501
Datalogic	Windows Mobile	Alltel Windows Mobile, Mobile Elf QVGA Numeric, Mobile Elf QVGA QWERTY, Mobile Elf VGA Numeric, Mobile Elf VGA QWERTY, Mobile J Series, Pidion BIP-5000
Dell	Windows Mobile	Dell Windows Mobile, X51, X51v
Dopod	Windows Mobile	310, 557w, 577W, 586W, 595, 710 Plus, 818 Pro, 838 Pro, 838, 900, C500, C720W, C730, C750, CHT 9000, D600, D802, D810, D818c, Dopod Windows Mobile, E806c, M700, P100, P800W, S300, S500, S505, S610, S900c, S910, T5388, T5388w, T5399, T5588, T8388, T8588, Touch Cruise, Touch T32381, Touch Viva T2222, U1000

Emobile	Windows Mobile	Dual Diamond S22HT, Emonster lite S12HT, Touch Diamond S21HT
Eriwin	Windows Mobile	ZX-C5000, ZX-G3+, ZX-K950, ZX-M3, ZX-Q4, ZX-T3333, ZX-T5000
Eten	Windows Mobile	Eten Windows Mobile, G500, G500+, Glofiish DX900, Glofiish M750, Glofiish M800, Glofiish M810, Glofiish V900, Glofiish X500, Glofiish X500+, Glofiish X600, Glofiish X610, Glofiish X650, Glofiish X800, Glofiish X900, M550, M600, M600+
Everex	Windows Mobile	Everex Windows Mobile, NEON
Fifth Media	Windows Mobile	A308, Fifth Media Windows Mobile
FirstOne	Windows Mobile	W38
Fly	Windows Mobile	Fly Windows Mobile, IQ-110, IQ-120, PC100, PC200, PC300
FUCHEN	Windows Mobile	FCB092
Fujitsu Siemens	Windows Mobile	Fujitsu Siemens Windows Mobile, Pocket LOOX C550, Pocket LOOX N100, Pocket LOOX N110, Pocket LOOX N500, Pocket LOOX N520, Pocket LOOX N560, Pocket LOOX T810, Pocket LOOX T830
Garmin-Asus	Windows Mobile	M10, M10E, M20, nuvifone M10 NA
Getac	Windows Mobile	PS236
Gigabyte	Windows Mobile	Gigabyte Windows Mobile, GSmart 2005, GSmart i, GSmart i+, GSmart i120, GSmart i128, GSmart i200, GSmart i300, GSmart i350, GSmart MS800, GSmart MS802, GSmart MS804, GSmart MS808, GSmart MS820, GSmart MW700, GSmart MW702, GSmart MW720, GSmart MW998,

		GSmart q60, GSmart S1200, GSmart S1205, GSmart t600
Gresso	Windows Mobile	Avantgarde Luna Gold, Avantgarde Luna Steel, Avantgarde Skeleton, Avantgarde Sol Gold, Black Diamonds, Royal Black Diamonds
Grundig	Windows Mobile	GR980, Grundig Windows Mobile
HB	Windows Mobile	330
Hewlett-Packard	Windows Mobile	Hewlett-Packard Windows Mobile, iPAQ 111 Classic, iPAQ 114 Classic, iPAQ 211 Enterprise, iPAQ 214 Enterprise, iPAQ 500, iPAQ 510, iPAQ 512, iPAQ 514, iPAQ 614 Business, iPAQ 614c, iPAQ 910, iPAQ 912, iPAQ 914c, iPAQ Glisten, iPAQ hw6910, iPAQ hw6915, iPAQ hw6920, iPAQ hw6925, iPAQ hw6940, iPAQ hw6945, iPAQ hw6965, iPAQ hx2190, iPAQ hx2195, iPAQ hx2490, iPAQ hx2495, iPAQ hx2790, iPAQ hx2795, iPAQ hx4705 (Windows Mobile 5), iPAQ K3 Glisten, iPAQ rw6815, iPAQ rw6818, iPAQ rw6828, iPAQ rx1950, iPAQ rx1955, iPAQ Voice Messenger
Highscreen	Windows Mobile	Hippo, Nano
HKC	Windows Mobile	C880, G1000, G801, G901, G908, G920, Mopad 8, Mopad 8E, Pearl, Prado, W1000
HP	Windows Mobile	iPAQ 610, iPAQ 610c, iPAQ 910c, iPAQ 914, iPAQ Data Messenger
HTC	Windows Mobile	5800, 6800, Advantage X7500, Advantage X7501, Advantage X7510, Apache, Artemis, Athena, Atlas, Breeze 100, Breeze, Cavalier, Dash 3G, Douton, Elf, Erato, Excalibur 160, Excalibur, Faraday, Galaxy, Gene, HD Mini, HD2 T9193, HD2, Herald, Hermes, HTC Windows Mobile, Imagio, Kaiser, Kii, Libra 100, Libra, Love,

		<p>MAX 4G, Mogul, Monet, Mteor, Muse, Nike, Omni, Oxygen, Ozone, P3000, P3300, P3400, P3400i, P3470, P3600, P4350, P6000 Census, Panda, Pharos, Prophet, Pure, Qilin, Raphael, S1200, S310, S411, S510 Snap, S520 Phoebus (Juno), S620, S621 Excalibur, S630, S640, S650, S710, S740, S743 US, Sedna, Sirius, Snap CDMA, Snap S511, Snap S521, Snap US S522, Snap, Star Trek, Startrek 100, Startrek, Tianxi T9188, Tilt 2, Titan, Tornado Noble, Tornado Tempo, Tornado, Touch 3G T3232, Touch CDMA, Touch Cruise P3650, Touch Cruise, Touch Cruise2, Touch Diamond CDMA P3051, Touch Diamond P3700, Touch Diamond P3702 Victor, Touch Diamond, Touch Diamond2 T5353, Touch Dual P5310, Touch Dual, Touch HD T8282, Touch HD T8285, Touch P3452, Touch Pro, Touch Pro2 CDMA, Touch Pro2 T7381, Touch Pro2, Touch Viva 2223, Touch, Touch2 T3333, Trinity, TyTN, Tytn-II, Universal, Volans, Vox, Whitestone, Wings 100, Wings, Wizard</p>
Huawei	Windows Mobile	C8000, C8100
iCEphone	Windows Mobile	The Medical Phone
IDEM	Windows Mobile	A4VC
iDO	Windows Mobile	P890, S600, S601, S630
I-Mate	Windows Mobile	810F Hummer
i-mate	Windows Mobile	810-F, i-mate Windows Mobile, Jama 101, Jama 201, Jama, Jamin, JAQ, JAQ3, JAQ4, JasJam, JasJar, K-Jam, KJAR, PDA-L, PDA-N, SmartFlip, SP5, SP5m, SP6, SPjas, SPL, Ultimate 5150, Ultimate 6150,

		Ultimate 7150, Ultimate 8150, Ultimate 8502, Ultimate 9150, Ultimate 9502
i-teq	Windows Mobile	Bond, i-teq Windows Mobile, Laser, X-Bond
IzenMobile	Windows Mobile	IzenMobile Windows Mobile, KRMA, KSMT
Kenix	Windows Mobile	E71, F458, K96, K97, K98, L302, L306, N69, X310, Z310
Kinpo	Windows Mobile	Everex NEON, iDO S601, iDO S630, Kinpo Windows Mobile, SP70, SP70R, SP90
Kyocera	Windows Mobile	Kyocera Solo
Laser	Windows Mobile	mLaser
Lenovo	Windows Mobile	ET600, ET860, ET960, ET980, i921, Lenovo Windows Mobile
LG	Windows Mobile	CT810, eXpo, Fathom, GM550, GM730, GM730f, GM750, GT810H, GW550, GW820, GW825 IQ, Incite, KC1, KS20, KU2100, LG KT878, LG Windows Mobile, LU2100, MS25, SU210
Lobster	Windows Mobile	700 TV
M3Mobile	Windows Mobile	M3 Orange AlphaNumeric M3-20, M3 Orange QWERTY M3-20, M3 Sky+, M3 Smart, M3 T MC-6700S
Microsoft	Windows Mobile	KIN ONE, KIN ONEm, KIN TWO, KIN TWOm
Mio	Windows Mobile	A502, A702, Explora K70, Explora K75, Mio P550, Mio P560, Mio Windows Mobile, P360, P550, P560
Mitac	Windows Mobile	A201, A501, A701, Mio A201, Mio P350, Mitac Windows Mobile
Mobile Compia	Windows Mobile	M3 Green MC-6100, M3 Green MC-6300, M3 Green MC-6400, M3 Green MC-6410, M3 Green MC-6600, M3 POS MC-8800, M3 Sky White MC-7100S, M7, MM3 MC-8000

Mobinnova	Windows Mobile	ICE 5420, ICE US
Modeo	Windows Mobile	Modeo
Motorola	Windows Mobile	A3000, A3100, ES400, FR6000, FR68, Franklin, i930, MC35, MC55, MC5574, MC65, MC70 CDMA, MC70 GSM, MC75 CDMA, MC75 GSM, MC9000, MC9090-G, MC909X-K, MC909X-S, MC9500-K CDMA, MC9500-K GSM, MOTO Q, MOTO Q11, MOTO Q8, MOTO Q9c, MOTO Q9h, MOTO Q9m, Motorola Windows Mobile, Norman, Q9
MWG	Windows Mobile	Atom V, MWG Windows Mobile, Zinc II
NDrive	Windows Mobile	S400
Neonode	Windows Mobile	N2, Neonode Windows Mobile
NTT DoCoMo	Windows Mobile	dynapocket T-01B, FOMA F1100, hTc Z, PRO series HT-01A, PRO series HT-02A, PRO series SC-01B
O2	Windows Mobile	O2 Windows Mobile, XDA Argon, XDA Atmos, XDA Atom Exec, XDA Atom Life, XDA Atom Pure, XDA Atom, XDA Cosmo, XDA Diamond Pro, XDA Exec, XDA Flame, XDA Flint, XDA Graphite, XDA Guide, XDA IQ, XDA Mantle, XDA mini S, XDA Neo, XDA Nova, XDA Orbit, XDA Orion, XDA Phone, XDA Serra, XDA Stealth, XDA Terra, XDA Trion, XDA Venn, XDA Zest, XDA Zinc
Okwap	Windows Mobile	K728, K868, K869, K871, Okwap Windows Mobile, S868
Opticon	Windows Mobile	H16, H16B, H19, H19B
Orange	Windows Mobile	Orange Windows Mobile, SPV C100, SPV C200, SPV C600 Superclub Edition,

		SPV C600, SPV C700, SPV E600, SPV E650, SPV F600, SPV M3000, SPV M3100, SPV M5000, SPV M600, SPV M650, SPV M700, SPV-E610
ORSiO	Windows Mobile	G735, N725 GPS, N725, ORSiO Windows Mobile, P745
Palm	Windows Mobile	Palm Windows Mobile, Treo 500, Treo 700w, Treo 700wx, Treo 750, Treo 750v, Treo 800w, Treo Pro CDMA, Treo Pro
Pantech	Windows Mobile	DUO C810, Duo, Matrix Pro, Mustang 2, Pantech Duo, Pantech Windows Mobile, PN820
Paragon Wireless	Windows Mobile	Hipi-2200, Hipi-2300, Paragon Wireless Windows Mobile
Pharos	Windows Mobile	600 GPS Phone, Pharos Windows Mobile, PTL565E, Traveler 117, Traveler 127, Traveler 137, Traveler 619, Traveller GPS 525
Philips	Windows Mobile	D900 Black, D908 Gray, D908 Red, Xenium V816 Black
Pocket Navigator	Windows Mobile	PN-3550, PN-3560, PN-P201, PN-P550 A, PN-P550, Pocket Navigator Windows Mobile
Psion Teklogix	Windows Mobile	Ikon, Psion Teklogix Windows Mobile, WORKABOUT PRO 3 C, WORKABOUT PRO 3 S QWERTY, WORKABOUT PRO 3 S, WORKABOUT PRO G2, WORKABOUT PRO
QiGi	Windows Mobile	AK007, AK007C, AK008C, AK008W, i6C, QiGi W900, Smartbook III U3000, Smartbook III V3000, Smartbook U1000, Smartbook U2000, T900, U6, U6P, U700, U700D, U8, U8P, U96, V800, V808, V880, V96, W700, W700B, W86, W86B
Qool Labs	Windows Mobile	QDA Icon, QDA Lite, Qool Labs Windows Mobile, Twins 178
Qtek	Windows Mobile	8300, 8310, 8500, 8600, 9000, 9100, 9600, G100, G200,

		Qtek Windows Mobile, S200, S310
Quanta	Windows Mobile	Apollo, Atom Exec, Atom Pure, Atom, Quanta Windows Mobile
Quest	Windows Mobile	Pocket PC6700, Quest Windows Mobile
Reliance	Windows Mobile	Mobile Pocket PC
RoverPC	Windows Mobile	C6, C7, E5, Evo V7, Evo X7, Evo X8 Black, Evo X8 White, Evo X8, EvoX7, G5, G6, Indigo, M5, N6, N7, P6, P7, Pro G8 Black, Pro G8 White, Q5, Q6, Q7, R5, RoverPC Windows Mobile, S5, S6, S7, S8 Black, S8 Lite, S8 Premium, S8 White, S8, W5, X7
Samsung	Windows Mobile	Amoled, B7300 Omnia Lite, B7320 Omnia Pro, B7330 Omnia Pro, B7610 Omnia Pro, B7620 Armani 2, B7620 Armani, BlackJack II, Code, Epix, Exec, GT-B5620 OmniaPRO 5, GT-B7300, GT-B7300C, GT-B7320L OmniaPRO, GT-B7330, GT-B7350 OmniaPRO 4, GT-B7610, GT-B7620, GT-C6620, GT-C6625, GT-C6625v, GT-I8000 Omnia II, GT-I8000L Omnia II, GT-i8000T Omnia Icon, GT-I8000U M2, i910 Omnia I, Multi-Touch, Omnia, Propel Pro, Samsung Windows Mobile, SCH-I329, SCH-I600, SCH-I760, SCH-I770, SCH-I910, SCH-I920, SCH-M480, SCH-M490, SCH-M495, SCH-M620, SCH-M710, SCH-M715, SCH-M720, SCH-M7200, SCH-M830, SGH-i200, SGH-I220, SGH-i310, SGH-i320, SGH-I320n, SGH-I326 Black, SGH-i600, SGH-I607, SGH-I608, SGH-I616, SGH-I617, SGH-I617T, SGH-I627, SGH-I637, SGH-I640, SGH-I640v, SGH-i710, SGH-i718, SGH-I718+, SGH-I720, SGH-I728, SGH-i740, SGH-I740C, SGH-I750, SGH-i760, SGH-i780, SGH-i900 (WITU), SGH-I900 WiTu, SGH-I900L, SGH-I900V, SGH-I907, SGH-I908, SGH-

		I908E, SPH-i325, SPH-I350, SPH-M4655, SPH-M4800, SPH-M6200 Ultra Messaging, SPH-M7350, SPH-M8100, SPH-M8200, SPH-M8400, WiTu Pro
SFR	Windows Mobile	V1605, V1640
Sharp	Windows Mobile	922SH, EM-ONE S01SH, EM-ONE S01SH2, Sharp Windows Mobile, W-ZERO3 (WS004SH)
Simvalley Mobile	Windows Mobile	Smartphone XP-25, Smartphone XP-45, Smartphone XP-65
Socket Mobile	Windows Mobile	SoMo 650 DX, SoMo 650
SoftBank	Windows Mobile	X01T
Softbank	Windows Mobile	X02HT, X03HT, X04HT Touch Diamond, X05HT Touch Pro
Sony Ericsson	Windows Mobile	M1a Aspen, M1i Aspen, Sony Ericsson Windows Mobile, XPERIA X1, XPERIA X1a, Xperia X2, Xperia X2a
Sprint	Windows Mobile	Ace, PPC-6700, Sprint Windows Mobile, Touch Pro, Touch Pro2
Sunno	Windows Mobile	Q880, S880
Swisscom	Windows Mobile	XPA v1240, XPA v1405
Tatung	Windows Mobile	M1, M1A
TDS	Windows Mobile	Nomad 800B, Nomad 800L, Nomad 800LC, Nomad 800LE, Ranger 300X, Ranger 500X, TDS Windows Mobile
TechFaith Wireless	Windows Mobile	G3000, SPL
Techfaith Wireless	Windows Mobile	Pebble
TechFaith Wireless	Windows Mobile	G3000, SPL
TechFaithWireless	Windows	Bono, Lancer, Lancer-C, Moffett,

	Mobile	Perai 850, Perai-H
Telecom New Zealand	Windows Mobile	Apache, Telecom New Zealand Windows Mobile
TMN	Windows Mobile	Bluebelt II, Bluebelt, Silverbelt
T-Mobile	Windows Mobile	Dash, MDA AMEO, MDA Compact II, MDA Compact III, MDA compact IV, MDA Dash, MDA Mail, MDA Pro, MDA Vario II, MDA Vario, SDA US, Shadow 2009, Shadow, T-Mobile Windows Mobile, Wing, Wings US
Torg	Windows Mobile	N100, P120
Toshiba	Windows Mobile	Dynapocket KG01, G810, Portege G500, Portege G710, Portege G810, Portege G900, Portege G910, TG01, TG02, Toshiba Dynapocket IS02, Toshiba Windows Mobile
Trimble	Windows Mobile	Juno SB, Juno SC
Typhoon	Windows Mobile	MyGuide Smartphone SP 700
UBiQUiO	Windows Mobile	501, 601, UBiQUiO Windows Mobile
Unitech	Windows Mobile	PA600 Phone Edition, PA968II Phone Edition, PA968II
UTStarcom	Windows Mobile	MP6900, SMT5800
Velocity Mobile	Windows Mobile	103, 111, Velocity Mobile Windows Mobile
Verizon Wireless	Windows Mobile	PN-820, SMT5800, Touch Diamond, Touch Pro, Touch Pro2, Verizon Wireless Windows Mobile, XV5800, XV6800, XV6900
Verizon	Windows Mobile	Verizon Windows Mobile
Vodafone	Windows Mobile	1210, 920, SP 1210, V1230, V1240, v1640, VDA GPS, VDA II, VDA IV, VDA V, Vodafone Windows Mobile,

		VPA Compact GPS, VPA Compact II, VPA Compact III, VPA Compact IV, VPA Compact s, VPA III, VPA IV
Voxtel	Windows Mobile	Voxtel Windows Mobile, W210, W420, W520, W740
Wanxin	Windows Mobile	M1
ZTE	Windows Mobile	e760, e810, e811, Raise, Xiang
ZyXel	Windows Mobile	V660

Hersteller	Plattform	Modelle
BlackBerry	RIM	8100, 8110, 8120, 8130, 8230 Flip, 8300, 8310, 8320, 8330, 8350i, 8500, 8520, 8530, 8800, 8820, 8830, 8900, 8910, 9100 Pearl 3G, 9105 Pearl 3G, 9300, 9330, 9500, 9520 or 9550, 9520, 9530, 9630 Tour, 9650 Bold, 9670, 9780, 9790, 9800 Torch, 9810, 9850, 9860, BBB, Bold Touch 9220, Bold Touch, Bold, Curve 9310, Curve 9320 SKU1, SKU2, Curve 9350, Curve 9360, Curve 9370, Curve Touch 9380, Flip 8220, IPD, P9981 Porsche Design, Storm 9530T

Hersteller	Plattform	Modelle
Samsung	Bada	Wave 3, Wave 525, Wave 533, Wave 575, Wave 578, Wave 723, Wave II, Wave M, Wave Y, Wave
Samsung	Swift	SGH-A226, SGH-A227, SGH-A237, SGH-A516, SGH-D500, SGH- D500E, SGH-D508, SGH-D510, SGH-D600, SGH-D600E, SGH- D608, SGH-D610, SGH-D618, SGH-D820, SGH-D820E, SGH- D828, SGH-D828E, SGH-D888+, SGH-D900, SGH-D900i, SGH- D908, SGH-D908i, SGH-E200, SGH-E200B, SGH-E208, SGH-

		<p>E208B, SGH-E236, SGH-E250, SGH-E250D, SGH-E250i, SGH-E250W, SGH-E251, SGH-E251C, SGH-E256, SGH-E258, SGH-E258D, SGH-E340, SGH-E348, SGH-E350, SGH-E358, SGH-E360, SGH-E368, SGH-E370, SGH-E370L, SGH-E378, SGH-E380, SGH-E388, SGH-E390, SGH-E398, SGH-E480, SGH-E488, SGH-E500, SGH-E508, SGH-E590, SGH-E598, SGH-E640, SGH-E648, SGH-E690, SGH-E698, SGH-E730, SGH-E736, SGH-E738, SGH-E740, SGH-E747, SGH-E748, SGH-E750, SGH-E758, SGH-E760, SGH-E768, SGH-E780, SGH-E788, SGH-E830, SGH-E838, SGH-E840i, SGH-E848i, SGH-E890, SGH-E898, SGH-F110, SGH-F118, SGH-F150, SGH-F158, SGH-F250, SGH-F250L, SGH-F258, SGH-F260, SGH-F265, SGH-F268, SGH-F270, SGH-F270L, SGH-F278, SGH-F480, SGH-F480L, SGH-F480t, SGH-F480V, SGH-F488E, SGH-G600, SGH-G608, SGH-G618, SGH-G808E, SGH-I858, SGH-J150, SGH-J158, SGH-J210, SGH-J218, SGH-J700, SGH-J700L, SGH-J700V, SGH-J706, SGH-J708, SGH-J708C, SGH-J808E, SGH-L250, SGH-L258, SGH-L310, SGH-L318, SGH-L600, SGH-L608, SGH-L750, SGH-M150, SGH-M158, SGH-M3510, SGH-M610, SGH-M618, SGH-P180, SGH-P200, SGH-P220, SGH-P240, SGH-P260, SGH-P780, SGH-P788, SGH-P850, SGH-P858, SGH-T219, SGH-T229, SGH-T301, SGH-T309, SGH-T329, SGH-T336, SGH-T339, SGH-T409, SGH-T429, SGH-T439, SGH-T459, SGH-T509, SGH-T619, SGH-T709, SGH-T729, SGH-T739, SGH-T809, SGH-U708E, SGH-U808E, SGH-U900, SGH-U900L, SGH-U908E, SGH-X437, SGH-X576, SGH-X670, SGH-X678, SGH-X690, SGH-X698, SGH-X700, SGH-X708</p>
Samsung	Sysol	<p>SCH-U350 Smooth, SGH-A137, SGH-A26A, SGH-A437, SGH-B110,</p>

		SGH-B110L, SGH-B130, SGH-B130S, SGH-B138, SGH-B210, SGH-BC01, SGH-C160, SGH-C160B, SGH-C160G, SGH-C161, SGH-C165, SGH-C168, SGH-C168B, SGH-C180, SGH-C280, SGH-C288, SGH-C327, SGH-C420, SGH-C425, SGH-C426, SGH-C450, SGH-C458, SGH-CC03, SGH-D488, SGH-E100, SGH-E108, SGH-E1110, SGH-E330, SGH-E330C, SGH-E330N, SGH-E335, SGH-E338, SGH-E420, SGH-E428, SGH-E630, SGH-E630C, SGH-E638, SGH-E700, SGH-E700A, SGH-E708, SGH-E746, SGH-E800, SGH-E800C, SGH-E808, SGH-E820, SGH-M110, SGH-M120, SGH-M130L, SGH-M140, SGH-S500, SGH-S508, SGH-T101, SGH-T101G, SGH-T109, SGH-T209, SGH-T319, SGH-T329, SGH-X100, SGH-X108, SGH-X460, SGH-X490, SGH-X495, SGH-X497, SGH-X540, SGH-X550, SGH-X560, SGH-X560L, SGH-X566, SGH-X600, SGH-X600A, SGH-X608, SGH-X620, SGH-X628, SGH-X640, SGH-X648, SGH-X650, SGH-X658
--	--	---

Manufacturer	Platform	Models
Motorola	Motorola classic phones (non-smartphone)	T720, T720i, T721, T725 A810, MOTO W388, MOTO ZN200, MOTOROKR EM28 (EM330), MOTOROKR EM30, MOTOZINE ZN5, ROKR EM25 (MOTO EM325), VE538 A845, C380, C650, C980, E1000, E1070, E380, E398, E550, E770, L2, L6, L6i, MOTO Z9 (Z9N), MOTOACTV W6, MOTOKRZR K1, MOTOKRZR K3, MOTOPEBL U3, MOTOPEBL U6, MOTORAZR maxx V6, MOTORAZR V3 (CLDC

		1.0), MOTORAZR V3 (CLDC 1.1), MOTORAZR V3, MOTORAZR V3e, MOTORAZR V3i, MOTORAZR V3im, MOTORAZR V3r, MOTORAZR V3re, MOTORAZR V3t, MOTORAZR V3v, MOTORAZR V3x, MOTORAZR V3xx, MOTORAZR2 V8, MOTORAZR2 V9, MOTORAZR2 V9x, MOTORIZR Z3, MOTOROKR E1, MOTOROKR E8, MOTOSLVR L7, MOTOSLVR L72, MOTOSLVR L7i, L7e, MOTOSLVR L9, V1050, V1100, V180, V195, V197, V220, V220ENS, V300, V360, V365, V400, V500, V550, V551, V551J, V600, V620, V635, V80, V975, V980, W230, W270, W490
--	--	---

iOS

iPhone, iPhone 3G, iPhone 3GS, iPhone 4, iPhone 4S, iPhone 5, iPad, iPad 2, iPad 3, iPad 4, iPad Mini und iPod Touch – nur Geräte mit Jailbreak!

1und1	Android	SmartPad
360 Qihoo	Android	Uniscope Small C
3Q	Android	Qoo! Surf TS1003T, Qoo! Surf TS1004T, Qoo! Surf TS1005B, Qoo! Surf TS1009B, Qoo! Surf TS1010C, Qoo! Surf TS1011B, Qoo! Surf TS1013B, Qoo! Surf TS1014B
Acer	Android	AT390, beTouch E110 B, beTouch E110, beTouch E120 black, beTouch E120 white, beTouch E130, beTouch E140, beTouch E210, beTouch E400, CloudMobile S500, Iconia Smart S300, ICONIA TAB A100, Iconia Tab A101, Iconia Tab A110, Iconia Tab A200, Iconia Tab A210 WiFi,

		Iconia Tab A211 3G, ICONIA TAB A500, Iconia Tab A501, Iconia Tab A510 Olympic Edition, Iconia Tab A510, Iconia Tab A700, Iconia Tab A701, Iconia Tab, Liquid A1, Liquid E Ferrari Edition, Liquid E, Liquid Express E320, Liquid Gallant Duo AK330, Liquid Gallant E350, Liquid Glow E330, Liquid Metal S120, Liquid mini E310 B, Liquid mt, Liquid Stream, Z110
Actwell	Android	Android Note
Ainol	Android	mini NOVO5 Basic, Novo Hero II, NOVO10 Hero, NOVO7 Advanced, NOVO7 Basic, NOVO8 Advanced
Alcatel	Android	One Touch OT-890, One Touch OT-890D, One Touch OT-903, One Touch OT-903D, One Touch OT-906, One Touch OT-908, One Touch OT-908F, One Touch OT-909, One Touch OT-909S, One Touch OT-910, One Touch OT-913, One Touch OT-915, One Touch OT-916, One Touch OT-916D, One Touch OT-918, One Touch OT-918D, One Touch OT-918MIX, One Touch OT-922, One Touch OT-980, One Touch OT-980A, One Touch OT-981A, One Touch OT-983, One Touch OT-985, One Touch OT-985D, One Touch OT-985N, One Touch OT-986, One Touch OT-990, One Touch OT-990A, One Touch OT-991D, One Touch OT-992D, One Touch OT-993, One Touch OT-993D, One Touch OT-995, One Touch OT-996, One Touch OT-997, One Touch OT-997D, One Touch OT-998, One Touch OT-T10, One Touch Scribe HD OT-8008D, One Touch T10, One Touch T20, OneTouch Move, OneTouch OT-990 Carbon, OneTouch OT-990 Chrome, OneTouch OT-991 Play, OT-891 Soul, Venture
Altek	Android	Leo A14
Amazon	Android	Kindle Fire (2gen), Kindle Fire HD 7, Kindle Fire HD 8.9 WAN, Kindle Fire HD 8.9 Wi-Fi, Kindle Fire
AnyDATA	Android	AnyTAB AMD120, AnyTAB AMD810, Duet ASP320
Aodini	Android	Android tablet
Archos	Android	101 G9 Turbo, 101 G9, 80 G9 Turbo, 80 G9, A101 Internet Tablet, A28 Internet Tablet, A32 Internet Tablet, A43 Internet Tablet, A48 Internet Tablet, A5 Internet Tablet, A7 Home Tablet, A70 Internet Tablet, A8 Home Tablet, Elements 80 Cobalt,

		Elements 97 Carbon, Elements 97 Xenon, Gen10 101 XS, Gen10 80 XS, Gen10 97 XS
Asus	Android	Eee Pad MeMO 171 ME370T, Eee Pad MeMO 3D, Eee Pad Slider SL101, Eee Pad Transformer Prime TF201, Eee Pad Transformer Prime TF300T, Eee Pad Transformer TF101, Eee Pad Transformer TF101G, Eee Pad Transformer TF101-WiMAX, ETBW11AA, PadFone 2, Padfone, Transformer Pad 300 3G, Transformer Pad 300 WiFi, Transformer Pad Infinity , Eee Pad Transformer Prime TF700T, Transformer Pad Infinity 3G TF700TG, Transformer Pad Infinity 4G LTE TF700TL, Transformer Pad Infinity
BBK	Android	Vivo X1
BeeLine	Android	E300
Beitel	Android	Magiq Glide, Magiq II
Bifer	Android	Firefly
Big	Android	Cola
Blu	Android	Magic, Tango
BlueBird	Android	Pidion Android Business Pad BP50, Pidion BIP-6000Max, Pidion BM-170
Bluebo	Android	L100
BN	Android	NOOK Tablet
Camangi	Android	FM600, WebStation
Casio	Android	Casio GzOne Commando, GzOne Type-L CAL21, V-T500-J, V-T500-WJ
Chang Jiang	Android	P5
Changhong	Android	V8, V9
China Mobile	Android	Mini 3i
Chuwi V99	Android	V99
Cinte	Android	4gs Android A8, A738, C700, C703, C708, C709, CT001, Desire HD V8, FG8, G2, i9000 mini, Legend G6, Star A2000, Star A3, Star A3000, Star A5000, Star A9000, ZT-180 A9 EPAD
Commtiva	Android	Linx N700
CompuLab	Android	Exeda Android 1.6
Coolpad	Android	8950 MagView II, Quattro 4G 5860E
CoolPad	Android	HD 9960
Coolpad	Android	8950 MagView II, Quattro 4G 5860E
Creative	Android	ZEN Touch 2, Zii Egg, ZiiO 10, ZiiO 7

CUBE	Android	U80 GT Mini, U9GT3
Dapeng	Android	A75, A8500
DataWind	Android	Aakash 2 UbiSlate 7+
Dell	Android	Aero, Flash, Mini3i, Mini3iX, Mini5, Streak 10 Pro WiFi, Streak 7 Wi-Fi, Streak 7, Streak Pro 101DL, Streak, Venue Pro, Venue, XCD28, XCD35
Deovo	Android	Neptune V5
Diadem	Android	MG902, MG909, MG910, MG986, MG988, MP308, MP310, MS830, MS831, MS907, MS908
Difo	Android	W500
Digma	Android	A5, d700, d701, D-Plane2 7" iDxD7 3G, D-Plane2 7" iDxD7, D-Plane2 8" iDxD8 3G, D-Plane2 8" iDxD8, D-Plane2 9.7" iDxD10 3G, D-Plane2 9.7" iDxD10, iD7, iDj7, iDj7n, iDn7 3G, iDs10 3G, iDs10, iDs7, iDx10 3G, iDx10, iDx5 3G, iDx5, iDx7, iDx8 3G, iDx8, iDx9 3G, iDx9
DoCoMo	Android	HT-03A
DOOV	Android	iEva D9
Dopod	Android	A3288, A6388, A8188, Hero A6288, Magic A6188, Magic A6188w
Dreambook	Android	W7
Eken	Android	M001, M002, M003, M005, M006
enTourage	Android	eDGe
Era	Android	G1
Eriwin	Android	ZX-A101, ZX-A103, ZX-A1200, ZX-A3, ZX-A3000, ZX-A5, ZX-A5000, ZX-A7000, ZX-A738, ZX-A8300 TV WIFI GPS, ZX-A8500, ZX-A9100, ZX-A919, ZX-A9191, ZX-A920, ZX-B1000, ZX-B63M, ZX-B72M, ZX-E909, ZX-F603, ZX-F606, ZX-FG10, ZX-FG8, ZX-FN8, ZX-G12, ZX-G14, ZX-G17, ZX-G2, ZX-G510, ZX-H2000, ZX-H400, ZX-H4000, ZX-H4300, ZX-H7000, ZX-H7300, ZX-HD7, ZX-I9100, ZX-K600A, ZX-L601, ZX-LT18I, ZX-T710, ZX-T8500, ZX-W690, ZX-W7272, ZX-WG1107, ZX-X15I, ZX-X18I, ZX-X19I, ZX-Y801, ZX-Y803
Exper	Android	Easypad Tablet P10AN, Easypad Tablet P10ANG
Explay	Android	A230, A350, Advance, Infinity, Informer 701, Informer 702, Informer 703, Informer 704, Informer 705, Informer 706 3G, Informer 707, Informer 708 3G, Informer 804, Informer 901, Informer 920, Informer 921, MID-710, MID-715, MID-725 3G, MID-725, Star
FirstOne	Android	F910 B, F910, GW10, P5b, P5g, P5w, P7b, P7g,

		P7w
Fly	Android	IQ230 Compact, IQ235 Uno, IQ236 Victory, IQ240 Whizz, IQ245 Wizard, IQ245+ Wizard plus, IQ250 Swift, IQ255 Pride, IQ256 Vogue, IQ260 Blackbird, IQ270 Firebird, IQ275 Marathon, IQ280 Tech, IQ285 Turbo, IQ310 Panorama, IQ440 Energie, IQ441 Radiance, IQ442 Miracle, IQ444 Diamond, IQ450 Horizon, Vision
Forsa	Android	Posh.Pad MV7
Forward	Android	10.1-inch tablet, 9.7-inch MID tablet
FUCHEN	Android	A101, A103, A1-1, A2, A3, FC1002, FC701, FC702, FC703, FC705, FC707, FC801, FCB048, FCB703, FCR233, FCR235, MID97, S610, S710, S720, S810, S820
Fuchen	Android	A1-3, A5830, FCD021, i717, i9220, i9300, i9300, N9776 Note II, PDA8915 Android, V12
FUCHEN	Android	A101, A103, A1-1, A2, A3, FC1002, FC701, FC702, FC703, FC705, FC707, FC801, FCB048, FCB703, FCR233, FCR235, MID97, S610, S710, S720, S810, S820
Fuchen	Android	A1-3, A5830, FCD021, i717, i9220, i9300, i9300, N9776 Note II, PDA8915 Android, V12
FUCHEN	Android	A101, A103, A1-1, A2, A3, FC1002, FC701, FC702, FC703, FC705, FC707, FC801, FCB048, FCB703, FCR233, FCR235, MID97, S610, S710, S720, S810, S820
Fuchen	Android	A1-3, A5830, FCD021, i717, i9220, i9300, i9300, N9776 Note II, PDA8915 Android, V12
FUCHEN	Android	A101, A103, A1-1, A2, A3, FC1002, FC701, FC702, FC703, FC705, FC707, FC801, FCB048, FCB703, FCR233, FCR235, MID97, S610, S710, S720, S810, S820
Fuchen	Android	A1-3, A5830, FCD021, i717, i9220, i9300, i9300, N9776 Note II, PDA8915 Android, V12
FUCHEN	Android	A101, A103, A1-1, A2, A3, FC1002, FC701, FC702, FC703, FC705, FC707, FC801, FCB048, FCB703, FCR233, FCR235, MID97, S610, S710, S720, S810, S820
Fuchen	Android	A1-3, A5830, FCD021, i717, i9220, i9300, i9300, N9776 Note II, PDA8915 Android, V12
FUCHEN	Android	A101, A103, A1-1, A2, A3, FC1002, FC701, FC702, FC703, FC705, FC707, FC801, FCB048, FCB703, FCR233, FCR235, MID97, S610, S710, S720, S810, S820
Fuchen	Android	A1-3, A5830, FCD021, i717, i9220, i9300, i9300, N9776 Note II, PDA8915 Android, V12
FUCHEN	Android	A101, A103, A1-1, A2, A3, FC1002, FC701, FC702, FC703, FC705, FC707, FC801, FCB048, FCB703, FCR233, FCR235, MID97, S610, S710, S720, S810, S820
Fuchen	Android	A1-3, A5830, FCD021, i717, i9220, i9300, i9300, N9776 Note II, PDA8915 Android, V12

Fujitsu Toshiba	Android	IS11T Regza phone, ISW11F ARROWS Z
Fujitsu	Android	Arrows ES F-07D, Arrows ES IS12F, ARROWS X LTE F-05D, F-03D Girls, F-12C, REGZA Phone T-01D, Stylistic M350, CA2, Stylistic M532
Garmin-Asus	Android	A10, A50
Geeksphone	Android	One, Zero
General Mobile	Android	Cosmos, DSTL1
G-Five	Android	create A56, create A57, create A70, create A72, create A78, ESHARE A79, ESHARE A86, G95, I88
Gigabyte	Android	GSmart G1305 Boston, GSmart G1310, GSmart G1310D, GSmart G1315 Skate, GSmart G1317 Rola, GSmart G1317D, GSmart G1342, GSmart G1345, GSmart G1355, GSmart G1362, GSmart GS202, GSmart S1205
Ginwave	Android	GNote 2
Gionee	Android	GN858
GooApple	Android	V5 3G, V5+, V6
Google Asus	Android	Nexus 7
Google LG	Android	E960 Nexus 4
Google Samsung	Android	Nexus 10
Google	Android	Android Phone
GooPhone	Android	AK47, Goopad Mini, I5 Lite, i9220, S3, Y5, Y6
Goophone	Android	I5
GooPhone	Android	AK47, Goopad Mini, I5 Lite, i9220, S3, Y5, Y6
GPAD	Android	7" Gpad G13 Rockchips
Haier	Android	W718
Haipad	Android	A10A10, A9, i7, i7-T, M1001, M1002, M7, M7++, M701-R, M7-M, M7S, M7X, M8, M9, M9X, V7P
HaiPai	Android	x710d
Hannspree	Android	HANNS pad SN-10T1, HANNS pad SN-10T4, HANNS pad SN-70T1, HANNS pad SN-70T3
HB	Android	330(Q8), A101, A1-01, A103, A2, C3-01, GPS2000, L900, Q9, W102, W105
HDC	Android	A9100, I9300
HEDY	Android	H701, H706, H711, H712, H715, s801, s802, s803
hengda	Android	E7, Star A1000, Star A2000, Star A3000, Star A7000, Star A910, Star X12, WG1107, WG2000
Hengda	Android	i9350
hengda	Android	E7, Star A1000, Star A2000, Star A3000,

		Star A7000, Star A910, Star X12, WG1107, WG2000
Hero	Android	9300+, H200, H2000+, H4300
Hewlett-Packard	Android	Compaq AirLife 100
Highscreen	Android	PP5420, Zeus
Hivision	Android	PWS700CA
HOTT	Android	MD500
HTC (fake)	Android	HD9 - 3G
HTC	Android	Amaze 4G, Aria A6380, Aria, Butterfly X920d, ChaChaCha, Click, Desire A8183, Desire ADR6200, Desire ADR6275, Desire C, Desire HD A9191, Desire SV T326e, Desire V, Desire VC T328d, Desire VT T328t, Desire X, Desire X06HT, Desire Z A7272, Desire, Doubleshot, Dream, Droid DNA ADR6435, Droid Eris A6376, Droid Incredible 2 ADR6350, Droid Incredible 2, Droid Incredible 4G ADR6410, Droid Incredible 4G LTE, Droid Incredible ADR6300, Droid Incredible X, Droid Incredible, Edge, Eris, EVO 3D, Evo 4G LTE, EVO 4G, Evo Design 4G, EVO Shift 4G, EVO View 4G, EVO WiMAX ISW11HT, Explorer, Flyer 4G P515E, Flyer P510E, Flyer Wi-Fi P512, Gratia, Hero A6265, Hero A6277, Hero S, Hero, Icon, Incredible S (Vivo), Incredible S(Vivo), Inspire 4G, J Butterfly HLT21, J ISW13HT, J Z321e, Jetstream, Lead, Legend A6365 Bell, Legend, Lexikon (Merge), Magic, Nexus One, One S (Ville), One S Special Edition, One S Z250E, One SC, One ST, One SU, One SV EU, One V T320e (Primo), One VX, One X LTE Edge, One X Lte, One X Plus, One X S720e, One X, One XL, One XT S720t, Panache 4G (Emerald), Pyramid, Quattro, Raider 4G, Rezound, Rhyme, Rider, Saga (Desire S), Salsa (Weike), Sensation XE, Sensation XL, Shooter (ShooterU), Status, T328w (Wind), T329d, T329t, T9199, Tattoo, Thunderbolt 4G, Thunderbolt, Tianxi A9188, Triumph A8182, Ville, Vivid, Vivo (Incredible S), Vivo_w, Wildfire A315c, Wildfire A3335, Wildfire A3360, Wildfire A3380, Wildfire ADR6225, Wildfire S (Marvel), Wildfire S A510c, Wildfire, X920e
Huawei	Android	Ascend C8812, Ascend D LTE, Ascend D quad XL U9510E, Ascend D quad XL, Ascend D quad, Ascend D1, Ascend D2, Ascend G300 NFC, Ascend G300, Ascend G300C, Ascend G302D U8812D, Ascend G302D, Ascend G305T, Ascend G306T, Ascend G309T Pro,

		Ascend G312, Ascend G330, Ascend G510 T8951, Ascend G600, Ascend HW-01E, Ascend II, Ascend M860, Ascend Mate, Ascend P LTE , P1 4G U9202L, Ascend P LTE , P1 4G, Ascend P1 S, Ascend P1 TD T9200, Ascend P1, Ascend Y100, Ascend Y200, Ascend Y210, Boulder U8350, C8813, Deuce U8520, Emobile GS03, Glory M886, Honor 2 U9508, Huawei Ascend Y200T T8620, Ideos S7 Slim, Ideos S7-103, Ideos S7-104, Ideos S7-105, Ideos S7-201u Slim, Ideos U8150, Ideos X1 Gaga, Ideos X3, Ideos X5 Pro, Ideos X5 U8800, Ideos X5 U8800H, M660, M835, M865, MediaPad 10 FHD S10-101u, MediaPad 10 FHD, MediaPad 10 WiFi S10-101w, MediaPad 10 WiFi, MediaPad 7 Lite, S7-301c MediaPad, S7-301u MediaPad, S7-302u MediaPad 4G, Sonic U8650, Sonic U8652, T8301, T8833, U8100, U8110, U8160, U8220, U8230, U8300, U8500, U8836D, U8860, U9000, Vision
Hyndai	Android	A7
IBall	Android	Andi 2, Andi 3e, Slide
ICD	Android	Ultra, Vega
IDEM	Android	A9VC, G19, G23, N9+, Smart phones 520, Smart phones 5830, Smart phones 9070, Smart phones 9100
iHTC	Android	X310e
INQ	Android	Cloud Touch
Interpad	Android	10 Home Edition
Inventec	Android	N18 Dr. eye, N18C Dr. eye
JiaYu	Android	G2, G2S, G3, G4
JustCall	Android	PZ226+
Kai	Android	Excursion T1
Karbons	Android	A1, A5, A7, A9, Smart Tab 1
KDDI Fujitsu	Android	Arrows ef FJL21
KDDI Sharp	Android	Aquos Pad SHT21
KDDI	Android	iida INFOBAR A01
keenhigh	Android	MT791, RT791, WR761, WR762, WR850
Kenix	Android	A01, F458, Q7, Q8, V6, X1
K-Touch	Android	Hornet II
Kyocera	Android	Digno Dual WX04K, DIGNO ISW11K, Digno S isw11k, Digno S KYL21, Echo M9300, HONEY BEE 101K, HONEY BEE WX06K,

		Hydro C5170, Milano, Rise C5155, URBANO PROGRESSO, Zio M6000
Lava	Android	Xolo X900
Leguo	Android	fake iPhone
Lemon Mobiles	Android	P1 Smart
Lenovo	Android	A750, IdeaPad A2109, IdeaPad Tablet A1 WiFi, IdeaPad Tablet K1 WiF, IdeaPhone K900, IdeaTab A2107A, IdeaTab A2109, IdeaTab S2 10, IdeaTab S2109, K800, LePad A1-07 WiFi, LePad A2107, LePad A2207, LePad S2005, LePad S2007, LePad S2010, LePhone A360, LePhone A530, LePhone A580, LePhone A660, LePhone A800 Music phone, LePhone K2, LePhone K860, LePhone K860i, LePhone P700i, LePhone S2, LePhone S2-38AT0, LePhone S530, LePhone S560, LePhone S686, LePhone S880i, LePhone S890, LePhone S899t, LePhone, Mobile O1 ET70, oPhone, P770
LG	Android	Ally, Aloha, Andro-1, Apex, Axis, C550 Optimus Chat, C729 DoublePlay, C800 myTouch Q, Cosmos Touch, E2, E400 Optimus L3, E405 Optimus L3 Dual, E510 Optimus Hub, E610 Optimus L5, E739 myTouch, E970 Optimus G, E971 Optimus G, E972 Optimus G, E973 Optimus G, Enlighten, Esteem 4G, Etna, Eve, F100L Optimus Vu, F100S Optimus Vu, F120L Optimus LTE Tag, F-160K Optimus LTE2, F-160L Optimus LTE 2 , LTE2, F160L Optimus LTE II, F-160S Optimus LTE2, F-180S Optimus G, F-200L Optimus Vu II, G2x P999, Genesis, GW880, KU5900 Optimus Black, LG730 Venice, LGF100L Optimus Vu, LG-P985 Optimus Vu, LS670 Optimus S, LS696 Optimus Elite, LS840 Viper 4G, LS860 Cayenne 4G LTE, LS970 Eclipse 4G LTE, LU6200 Optimus LTE, LU6500 Optimus Q2, LU8800 Optimus Q2, LW770 Optimus Regard, Marquee, MS690 Optimus M, MS695 Optimus M+, MS770 Motion 4G, MS840 Connect 4G, MS910 Esteem 4G, Optimus 2X, Optimus 3D, Optimus Big, Optimus Black, Optimus Chic, Optimus G L-01E, Optimus Link, Optimus Mach, Optimus Me, Optimus Net, Optimus One, Optimus Pro, Optimus Q, Optimus S, Optimus Slider, Optimus Sol, Optimus Z, Optimus, P504 Optimus T, P509 Optimus T, P692 Optimus Net, P700 Optimus L7, P705 Optimus L7, P720 Optimus 3D Max, P720H Optimus 3D Max, P760 Optimus L9,

		P769 Optimus L9, P870 Escape 4G, P880 Optimus 4X HD (LG X3), P880G Optimus 4X HD, P895 Optimus Vu, P925 Thrill 4G, P929 Thrill 4G, P930 Nitro HD, P936 Optimus LTE, P940 Prada 3.0 (LG K2), P940H Prada 3.0 (LG K2), Revolution, SU370 Optimus One, SU640 Optimus LTE, SU870 Optimus 3D Cube, SU880 Optimus EX, US670 Optimus U, US730 Splendor, V900 Optimus Pad, V905 Optimus Pad, V909 G-Slate, VM670 Optimus V, VM696 Optimus Elite, VN270 Cosmos Touch, VS 920 Spectrum 4G, VS660 Vortex, VS840 Lucid 4G, VS930 4G, VS950 Optimus Vu LTE
LingHua	Android	GS30
Love	Android	Digital M971TG
MAG	Android	iMiTO iM7, iMiTO iM7S
Mathron	Android	A1, A10, A1000, A10S, A1200, A13, A1680, A2, A2000, A3, A4, A5000, A6, A6000, A701, A702, A710, A8, A80, A9000, A910+, A9191, A9220, A97, A9800, ATV Android 2.3.4 TV box, ATV-1, ATV-2, B1000, B2000+, B3000S, B4000, B79, BLY-866, C7, EA1010, F602, F603, F9191, FG8, Flytouch 3, G11, G12, G18, G20, G21, G22, G510, G7, GPAD G10, H7000, HD2000, HD7000, I9220+, K6000, KLM1001, KLM1005, KLM701, KLM704, KLM705, KLM710, KLM711, L01, L02, L03, L04, L06, L09, L10, L601, LT18I, M01C, M01D, M01E, M01F, M03, M03B, M06, M1001, M68, M701C, M706, M707, M709, M711A, MD 701, MD1001, MD701, MD701A, MD707, MD711D, MD713, MD818, MD9710, Mi88, MR003, MR005, MR006, MR403, MR501, MR70006, MR70007T, MR70009T, MR70012, MR70013, MR70014, MR70015(RK), MR712 Android, P800, Q7, Q81, Q900, Rockchip2818, S5000, S710, S820, SV25A, SV27A, SV27D, SV28B, T01, T02, T8800, TCC8902, TV01 Android 2.3 TV box, TV02 Android 2.3 TV box, V6C, V9I, w007, W008, W5000, W9100, X15I, X19I, X20I, x5a, Y005, Y802, Y808, Y901
Mediatek	Android	MTK chip-based Android phone
Meizu	Android	M9, MX 2, MX Quad-Core 64GB, MX
MENQ	Android	EasyPC E790 Android
Meox	Android	Phone 5S
Micromax	Android	A60, A70
MOGU	Android	M10

<p>Motorola</p>	<p>Android Admiral XT603, Atrix 2 MB865, Atrix 2 ME865, Atrix 3 MB886, ATRIX 4G, Atrix MB861, Atrix TV XT682, ATRIX, BACKFLIP ME600, BackFlip, Bionic XT875, Bravo MB520, Bravo, CHARM, Citrus WX445, CITRUS, CLIQ (DEXT), CLIQ 2, Defy Mini XT320, Defy Mini XT321, Defy XT XT556, Defy XT XT557, DEFY, DEFY+, Destino i867, DEVOUR, DROID 2 Global, DROID 3, DROID 4 XT894, DROID Bionic XT875, DROID RAZR HD XT926, DROID RAZR M 4G LTE XT907, DROID RAZR MAXX HD, DROID RAZR XT912, DROID X, DROID X2 MB870, DROID XYBOARD 8.2 MZ609 32GB, DROID XYBOARD MZ617 4G LTE 64GB, DROID, DROID2 A955, DROID3 XT862, ELECTRIFY 2 XT881, Electrify, ET1 Enterprise Tablet, FIRE XT XT530, FIRE XT317, FIRE, FLIPOUT, FLIPSIDE, i1, i940, Kronos MB6112, Master XT605, Milestone 2 A953, MILESTONE 2, Milestone 3 ME863, MILESTONE 3 XT883, Milestone A854, MILESTONE, MING MT810, MOTO A1260, MOTO A1680, MOTO GLAM XT800w, MOTO GLAM, MOTO MB612, MOTO ME525, MOTO ME525+, MOTO ME632, MOTO ME811, MOTO MIX, MOTO MT620, MOTO MT680, MOTO MT716, MOTO MT810lx, MOTO MT870, MOTO MT917, MOTO QRTY, MOTO RAZR V MT887, MOTO XT301, MOTO XT316, MOTO XT319, MOTO XT390, MOTO XT531, MOTO XT532, MOTO XT560, MOTO XT615, MOTO XT681, MOTO XT701, MOTO XT702, MOTO XT711, MOTO XT760, MOTO XT800, MOTO XT806, MOTO XT861, MOTO XT882, MOTOLUXE XT XT788, MOTOLUXE XT685, MOTOLUXE, MOTOSMART Flip XT611, MOTOSMART Mix XT550, MOTOSMART Mix XT553, MOTOSMART XT389, MT710 Zhiling, PHOTON 4G, Photon Q 4G LTE XT897, PRO XT610, Pro+ MB632, QUENCH XT3, QUENCH XT5, QUENCH, RARZ XT909, RAZR HD XT925, RAZR i MT788, RAZR i XT890, RAZR M 201M XT902, RAZR M 201M, RAZR M XT905, RAZR V XT885, RAZR V XT889, RAZR XT910, SPICE Key, SPICE, TITANIUM, TRIUMPH, XOOM MZ505 Family Edition, XOOM MZ602 4G LTE, XOOM, XOOM2 Media Edition MZ608,</p>
------------------------	--

		XOOM2 Media Edition WiFi MZ607, XOOM2 MZ616, XOOM2 WiFi MZ615, XT535 Defy XT, XT626 DOUBLE V, XT800c Titanium, XT860 4G, XT928, ZN4
Nec	Android	LifeTouch NOTE, MEDIAS N-01D, MEDIAS N-06C, Smartia
NEC	Android	Medias 101S, Medias CH 101N, Medias ES N-05D, Medias LTE N-04D, Medias N-04C, Medias Tab N-06D LTE, Medias Tab UL N-08D, Medias WP N-06C
Nec	Android	LifeTouch NOTE, MEDIAS N-01D, MEDIAS N-06C, Smartia
NEC	Android	Medias 101S, Medias CH 101N, Medias ES N-05D, Medias LTE N-04D, Medias N-04C, Medias Tab N-06D LTE, Medias Tab UL N-08D, Medias WP N-06C
Nec	Android	LifeTouch NOTE, MEDIAS N-01D, MEDIAS N-06C, Smartia
NEC	Android	Medias 101S, Medias CH 101N, Medias ES N-05D, Medias LTE N-04D, Medias N-04C, Medias Tab N-06D LTE, Medias Tab UL N-08D, Medias WP N-06C
Nec	Android	LifeTouch NOTE, MEDIAS N-01D, MEDIAS N-06C, Smartia
Newman	Android	N2
Newstar	Android	A9230 i9100, B2000, C71, C91, S103, S12, S4+, S5, S6000, S8, S810, S9, TAB007-3, TAB007-5, TAB008-1
Notion Ink	Android	Adam Variant A, Adam Variant B
NTT DoCoMo Fujitsu	Android	Arrows X F-10D, F-09D Anteprema
NTT DoCoMo LG	Android	L-06D Optimus Vu
NTT DoCoMo Sharp	Android	Aquos Phone si SH-01E, Aquos Phone sv SH-10D
NTT DoCoMo	Android	Arrows Me F-11D, Lynx 3D SH-03C
Olivetti	Android	OliPad 100, OliPad 110
Onkyo	Android	TA117C1, TA117C3
Oppo	Android	Find 5, Finder 5 HD, R817
Optima	Android	OP5-E
Optimus	Android	Boston
Orange	Android	San Francisco, Santa Clara, Tahiti
Panasonic	Android	ELUGA Live P-08D, ELUGA Power, ELUGA, LUMIX Phone 101, LUMIX Phone 102P, P-07C,

		Sweety SoftBank 003P, Toughpad FZ-A1
Pantech	Android	Breakout, Burst, Crossover P8000, Element, Flex P8010, IM-A600S Sirius, IM-A690S SKY, Marauder ADR910L, P9090, Perception ADR930L, Pocket, Sirius Alpha, SKY Izar IM-A630K, SKY Mirach A, SKY Mirach IS11PT, SKY Vega LTE EX IM-A820L, SKY Vega X IM-A720L, Vega LTE IM-A800S SKY, Vega LTE M IM-A810S SKY, Vega PTL21, Vega R3 IM-A850K, Vega R3 IM-A850L, Vega R3 IM-A850S, Vega Racer 2 LTE IM-A830K, Vega Racer 2 LTE IM-A830L, Vega Racer 2 LTE IM-A830S, Vega Racer IM-A760S, Vega Racer IM-A770K, Vega Racer IM-A780L
PHICOMM	Android	I800
Philips	Android	D633 White, D822 Black, GoGear Connect, T539 Black plus Gold, T910 White, V808 Black, V900 Black, V900 Silver, V900 White, V900, W337, W536 Gray, W536 Red, W635 Gray, W6350 Black, W6350 White, W820 Black, W920 Black plus Gold, Xenium V726, Xenium W626 Black, Xenium W626 White, Xenium W632 Black plus Gray, Xenium W732 Black, Xenium W736 Gray, Xenium W930 Black
PIPO	Android	S2
PocketBook	Android	A10, A7
ProMation	Android	Yi9300+
QiGi	Android	A1, i3
Qigi	Android	i6
Ramos	Android	W30HD, W31
Ritmix	Android	RBK-490, RBK-493, RBK-495, RBK-496, RMD-1020, RMD-1025, RMD-1030, RMD-1035, RMD-1050, RMD-520, RMD-700, RMD-720, RMD-721, RMD-725, RMD-730, RMD-740, RMD-750, RMD-830, RMD-835, RMD-900, RMP-400, RMP-500
Rogers	Android	Dream
RoverPC	Android	RoverPad 3W G70
Samsung	Android	Acclaim, Admire, Behold II, Captivate Glide, Captivate, Conquer 4G, Continuum, Dart, DoubleTime, Droid Charge, EK-GC100 Galaxy Camera, EK-KC100S Galaxy Camera, Epic 4g, Exhibit 4G, Fascinate, Galaxy 3, Galaxy 551, Galaxy Ace 2, Galaxy Ace, Galaxy Apollo, Galaxy Europa, Galaxy Fit, Galaxy Gio, Galaxy Lite, Galaxy Mini,

Galaxy Neo, Galaxy Nexus, Galaxy Note,
Galaxy Pop, Galaxy Portal, Galaxy Prevail,
Galaxy Pro, Galaxy Q, Galaxy R, Galaxy S Hoppin,
Galaxy S i909, Galaxy S II 4G,
Galaxy S II Epic 4G Touch, Galaxy S II Skyrocket,
Galaxy S Plus, Galaxy S scLCD, Galaxy S Wi-
Fi 4.0 (G1), Galaxy S Wi-Fi 5.0 (G70), Galaxy SII,
Galaxy Tab 10.1 (Verizon 4G LTE),
Galaxy Tab 10.1 (Wi-Fi Only),
Galaxy Tab 7.0 (ATT), Galaxy Tab 7.0 (CDMA),
Galaxy Tab 7.0 (Sprint), Galaxy Tab 7.0 (T-Mobile),
Galaxy Tab 7.0 (Wi-Fi Only),
Galaxy Tab 7.7 Plus SC-01E, Galaxy Tab 8.9 (Wi-
Fi Only), Galaxy Tab, Galaxy Y, Gem,
Giorgio Armani, Gravity SMART, GT-
B5510 Galaxy Y Pro, GT-B7800 Galaxy M Pro, GT-
B7810, GT-B9388, GT-I5700 Galaxy Spica, GT-
i5800L Apollo, GT-I7500 Galaxy, GT-
I7500L Galaxy, GT-i8190 Galaxy S III Mini NFC,
GT-I8320 Protector, GT-I8520 Galaxy Beam, GT-
I8530 Galaxy Beam, GT-I9000 Galaxy S, GT-
I9000M Galaxy S Vibrant, GT-I9008 Galaxy S, GT-
I9020T Nexus S, GT-i9050, GT-
I9070 Galaxy S Advance, GT-
I9070P Galaxy S Advance NFC, GT-
i9070P Galaxy S Advance, GT-I9100 Galaxy SII,
GT-I9203 Google Nexus S, GT-
I9210 Galaxy S II LTE EU, GT-
i9210 Galaxy S II LTE, GT-I9250 Galaxy Nexus,
GT-i9260 Galaxy Premier, GT-i9300 Galaxy S III,
GT-i9305 Galaxy S III LTE EU, GT-
i9305T Galaxy S III 4G, GT-i9308 Galaxy S3, GT-
N7000B Galaxy Note, GT-N7005 Galaxy Note LTE,
GT-N7100 Galaxy Note II, GT-
N7102 Galaxy Note II, GT-
N7105 Galaxy Note II LTE 32GB, GT-
N7105T Galaxy Note II LTE, GT-
N7108 Galaxy Note II, GT-
N8000 Galaxy Note 10.1, GT-
N8010 Galaxy Note 10.1 WiFi, GT-
P1000N Galaxy Tab 7.0, GT-
P3100 Galaxy Tab 2 7.0, GT-
P3110 Galaxy Tab 2 7.0 WiFi, GT-
P5100 Galaxy Tab 2 10.1, GT-P5100 Galaxy Tab 2,
GT-P5110 Galaxy Tab 2 10.1 WiFi, GT-
P6200 Galaxy Tab 7.0 Plus, GT-
P6201 Galaxy Tab 7.0 Plus N, GT-
P6210 Galaxy Tab 7.0 Plus WiFi, GT-
P6211 Galaxy Tab 7.0 Plus N, GT-
P6800 Galaxy Tab 7.7, GT-
P6810 Galaxy Tab 7.7 WiFi, GT-
P7100 Galaxy Tab 10.1v, GT-P7300 Galaxy Tab 8.9,

GT-P7320 Galaxy Tab 8.9 LTE, GT-P7500 Galaxy Tab 10.1, GT-P7501 Galaxy Tab 10.1N, GT-P7560 Galaxy Tab 7.0 Plus 16GB, GT-S5300 Galaxy Pocket, GT-S5302 Galaxy Pocket Duos, GT-S5512 Galaxy Y Pro Duos, GT-S5830T Galaxy Ace, GT-S6012 Galaxy Music Duos, GT-S6102 Galaxy Y Duos, GT-S6500 Galaxy Mini 2, GT-S6500D Galaxy Mini 2 NFC, GT-S7500 Galaxy Ace Plus, GT-S7562 Galaxy S Duos, Illusion, Indulge, Infuse 4G, Instinct Android, InstinctQ, Intercept, Mesmerize, Moment 2, Moment, Nexus S (Indian), Nexus S (T-Mobile), Nexus S 4G (CDMA), Nexus S, Replenish, Repp, Saturn, SC-05D Galaxy Note LTE, SCH-i200 Galaxy Stellar 4G, SCH-I405U Stratosphere 4G, SCH-i405U Stratosphere, SCH-i415 Stratosphere II, SCH-i535 Galaxy S3, SCH-i579 Galaxy Ace Duos, SCH-i605 Galaxy Note II LTE, SCH-i659 Galaxy Ace Plus, SCH-i699 Galaxy Trend, SCH-i705 Galaxy Tab 2 7.0 4G LTE, SCH-I815 Galaxy Tab 7.7, SCH-i829, SCH-I889 Galaxy Note, SCH-I899, SCH-i925U Galaxy Note 10.1 LTE, SCH-J021 Galaxy S III Progre SCL21, SCH-M510, SCH-N719 Galaxy Note 2 CDMA, SCH-R820 Galaxy Admire 4G, SCH-R830 Galaxy Axiom, SCH-R910 Galaxy Indulge, SCH-R940 4G LTE, SCH-W2013, SCH-W899, SGH-i317 Galaxy Note II LTE, SGH-i437 Galaxy Express, SGH-i497 Galaxy Tab 2 10.1, SGH-i577 Exhilarate, SGH-I717 Galaxy Note LTE, SGH-I757 Galaxy S II Skyrocket HD LTE, SGH-i757 Galaxy S II Skyrocket, SGH-I847 Rugby Smart, SGH-I957 Galaxy Tab 8.9 4G LTE, SGH-N025 Galaxy Note II SC-02E, SGH-N035 Galaxy S III Alpha SC-03E, SGH-T679 Exhibit II 4G, SGH-T679M Galaxy W 4G, SGH-T769 Galaxy S Blaze 4G, SGH-T779 Galaxy Tab 2 10.1 4G, SGH-T869 Galaxy Tab 7.0 Plus 4G, SGH-T879 Galaxy Note, SGH-T959D Galaxy S Fascinate 3G+, SGH-T959V Galaxy S 4G, SGH-T989 Galaxy SII, Showcase, SHV-E140S Galaxy Tab 8.9 LTE M32, SHV-E150S Galaxy Tab 7.7 LTE, SHV-E210S Galaxy S III, SHV-E230L Galaxy Note 10.1 LTE, SHV-E230S Galaxy Note 10.1 LTE, SHV-

		E250S Galaxy Note II LTE, SHW-M100S Galaxy A, SHW-M110S Galaxy S, SHW-M340S Galaxy M Style, SPH-L300 Galaxy Victory 4G LTE, SPH-L300, SPH-L700 Galaxy Nexus 4G LTE, SPH-L900 Galaxy Note II LTE, SPH-M830 Galaxy Rush, SPH-M950 Galaxy Reverb, Stratosphere Galaxy S, Transfix, Transform Ultra, Transform, Vibrant, YP-G1CW Galaxy S WiFi 4.0, YP-G1EW Galaxy S WiFi 4.0, YP-G70CW Galaxy S WiFi 5.0, YP-G70EW Galaxy S WiFi 5.0, YP-GB1EW Galaxy Player 16GB, YP-GB70EW Galaxy Player 70 16GB, YP-GB70NW Galaxy Player 70 32GB, YP-GP1 Galaxy Player 5.8 32GB, YP-GP50 Galaxy Player 50, YP-MB2 Yepp
Saygus	Android	Vphone V1
SciPhone	Android	N19, N21
Sharp	Android	Aquos 007SH The Hybrid, Aquos 101SH The Hybrid, Aquos 102SH, Aquos 103SH, Aquos 104SH, AQUOS PHONE f SH-13C, AQUOS PHONE IS11SH, AQUOS PHONE IS12SH, AQUOS PHONE IS13SH, AQUOS PHONE IS14SH, AQUOS PHONE SH-01D, AQUOS PHONE SoftBank 006SH, AQUOS PHONE THE HYBRID SoftBank 007SH J, Aquos SH-12C, Aquos, DM011SH, FX PLUS ADS1, Galapagos 10.8 Media Tablet, Galapagos 5.5 Media Tablet, GALAPAGOS SoftBank 005SH, IS01, IS03, IS05, LYNX SH-10B, SH330U, SH530U, SH631W, SH7218U, SH7228U, SOFTBANK 007SH KT
Simdo	Android	D98
SK Telesys	Android	SK-S100
SmartQ	Android	U7
SMiT	Android	MID-560
Socool	Android	S10
Softbank Sharp	Android	Aquos Phone Xx 203SH
SoftBank	Android	001HT Desire HD, 003Z
Softbank	Android	Galapagos, Pantone 6 200SH
Sony Ericsson	Android	A86, A8i, Android, Live with Walkman, SO-01B, SO-01C Sakura Pink, SO-01C, U8180, VM701 Optimus Slider, W8 Walkman E16a, WT18i, WT19a Walkman, Xperia Active,

		Xperia Arc HD, Xperia arc S, Xperia arc, Xperia mini pro, Xperia mini, Xperia Neo V MT11a, Xperia neo, Xperia play SO-01D, Xperia play, Xperia ray ST18a, Xperia X10 mini pro, Xperia X10 mini, Xperia X10a, Xperia X10i, Xperia X8
Sony Mobile	Android	Walkman NWZ-F806, Xperia acro HD SOI12, Xperia acro S LT26w, Xperia advance ST27a, Xperia AX SO-01E, Xperia E C1504, Xperia E C1505, Xperia E dual C1604, Xperia E dual C1605, Xperia Fusion SO-02E, Xperia go ST27a, Xperia go ST27i, Xperia GX SO-04D, Xperia Ion HSPA LT28h, Xperia J ST26, Xperia J ST26a, Xperia J ST26i, Xperia LT25i, Xperia Miro ST23a, Xperia Miro ST23i, Xperia neo L MT25i, Xperia SL LT26ii, Xperia T LT30at, Xperia T LT30p, Xperia Tipo Dual ST21a2, Xperia Tipo Dual ST21i2, Xperia TL LT30a, Xperia V LT25, Xperia V LT25c, Xperia VL SOL21, Xperia Z C6602 L36h, Xperia Z C6603 L36i, Xperia ZL L35a C6506, Xperia ZL L35i C6503
Sony	Android	Aoba, S1, S2, Walkman NW-Z1060, Walkman NW-Z1070, Xperia acro HD IS12S, Xperia acro HD SO-03D, Xperia arc LT26a, Xperia GX LT29a, Xperia GX LT29i, Xperia New eDream6 LT28i, Xperia NX SO-02D, Xperia P LT22a, Xperia P LT22i, Xperia ray ST18i, Xperia sola MT27i, Xperia ST21a, Xperia ST21i, Xperia SX SO-05D, Xperia U ST25a, Xperia U ST25i
Spice	Android	Mi-270, Mi-280, Mi-285, Mi-300, Mi-310, Mi-350, Mi-350n, Mi-355 Stellar Craze, Mi-410, Mi-415, Mi-500 Stellar Horizon, Mi-720
Sprint Samsung	Android	SPH-P500 Galaxy Tab 2 10.1 4G
Sprint	Android	Express, Intercept, Moment
Star	Android	A101, a3-3G, A500, A8, A9000, A910, A919, B29M, B79, G12a, G14, G17, G20, G22, Galaxy S3, i9100, i9220, i9250, LT18i, N8000, N9776, Star oneX ZC300, W007, W7272, W7272+ 3G, WG1000, X12 Multitouch, X12, X15i, X18i, X19i, X2, X26i
Subor	Android	Dream X
Sunle	Android	L450, L570S
TCL	Android	P600, S500, S900, Y600
TechFaithWireless	Android	Lancer Google, Lancer

Telstra Samsung	Android	GT-i9300T Galaxy
teXet	Android	TB-705A, TB-707A, TB-709A, TB-711A, TB-715A, TB-719A, TB-723A, TB-725A, TB-727A, TB-771A, TB-805A, TB-807A, TB-823A, TM-3000, TM-3200R, TM-4504, TM-4577, TM-5200, TM-5204, TM-5277, TM-7023, TM-7025, TM-7026, TM-7037W 3G
THL	Android	V11, V9, W3, W5
ThL	Android	V12
THL	Android	V11, V9, W3, W5
Tiger	Android	G3
T-Mobile HTC	Android	myTouch 4G
T-Mobile Huawei	Android	myTouch Q
T-Mobile Samsung	Android	SGH-T699 Galaxy S Relay 4G , Blaze Q, SGH-T889 Galaxy Note 2, Sidekick 4G SGH-T839
T-Mobile	Android	Comet U8150-B, G1, G2, Move, myTouch 3G, Prism U8651, Pulse, S7-303u SpringBoard 4G, Vivacity
Toshiba	Android	AC-100-10U, AT200, AT300SE, Dynabook AZ, Excite 10 LE AT205, Excite 10 T AT300, Excite 10.1 AT305, Excite 13 T AT330, Excite 13.3 AT335, Excite 7 T AT270, Excite 7 T, Excite 7.7, FOLIO 100, Regza IS04, Regza T-01C, Regza Tablet AT500 36F, Regza Tablet AT570 46F, Regza Tablet AT700 46F, Regza Tablet AT830 T6F, THRiVE 7, Thrive
TOTEMPO	Android	TOTEMPO-T7
TX	Android	A3000
Verizon Samsung	Android	SCH-i915 Galaxy Tab 2 10.1 4G
Videocon	Android	V7400, Zeus V7500
Viewsonic	Android	gTablet
ViewSonic	Android	V350, V430, ViewPad 10e, ViewPad 10s 3G, ViewPad 10s, ViewPad 4, ViewPad 7e, ViewPad 7x 3G, ViewPad E100, ViewPad e70, ViewPhone 3e, ViewPhone 4e, ViewPhone 4s, ViewPhone 5e
Viliv	Android	P3 Prime, X10 HSPA, X7 HSPA
Vivienne Westwood	Android	SH-01E
Vizio	Android	Via Tablet VTAB1008
Vodafone	Android	845, 945, SmartTab II A2107, VF845 Joy
Vsun	Android	i1
WayteQ	Android	X-Phone Android

WellcoM	Android	A66, A68, A69, A88 3G, WePAD A800
Xiao Mi	Android	C2000
Xiaomi	Android	1S standard edition, 1S youth edition, MI2
Yarvik	Android	GoTab Exxa TAB465EUK, GoTab Gravity TAB364, GoTab Slimline TAB411, GoTab Velocity TAB220, GoTab Velocity TAB224, GoTab Velocity TAB264, GoTab Xerios TAB420, GoTab Xerios TAB424, GoTab Xerios TAB461EUK, GoTab Xerios TAB464, GoTab Zetta TAB468EUK, TAB210, TAB211, TAB310, TAB410
Yuandao	Android	N90S
Zenithink	Android	C71, C91 ZT-280, C93, C97, N6, ZTPad C94
Zero	Android	Fire Ice E60
Ziss	Android	Cube MID, Jet Tablet, Jet Touch Tablet, Pub, Soho 3
Zoho	Android	WG1107
Zonda	Android	Raging 900
Zophone	Android	I5, S9
Zopo	Android	ZP100, ZP200, ZP300 Field, ZP500 Libero
ZOPO	Android	ZP900 Leader, ZP900S lite
ZOppo	Android	ZP900
ZTE	Android	Aglaia, Amigo, Avail, Blade II, Blade S, Blade, Crescent, EasyTouch 4G, Era, Flash N9500, FTV phone, Fury N850, Grand Era LTE V9800, Grand Era U985, Grand Era, Grand X IN 16GB, Grand X IN P940, Grand X LTE T82, Grand X N970, Grand X V970T, Libra, Ligh Tab V9C, Light Plus, Light Pro, Light Tab V9A, Light Tab V9S, Light, Link, Lutea, Mercury, Micromax A60, Mimosa X, N721, N8300, N880E, N910, N9120 Avid 4G, Nova 4.0 V8000, Nova V6500, Nubia Z5, Nubia, P945, PF100, PF112, PF200 EU, PF200, R750, Racer II, Racer, Score M, Score X500 M, Score X500, Score, Skate Acqua, Skate Kis, Skate, Smooth, STAR 7 009Z, Style Q, T72, T81, T98, Tureis, U887, U900, U950, U960s3, V790, V821, V8300, V852 Dreamer, V871, V880F, V881, V882, V887, V889M, V9, V9+, V970, Viettel V8403, Warp Sequent, Warp, X501, ZTE Fury N850

Accord	MTKTEMPLATE	A19
Afone	MTKTEMPLATE	H880
Agitel	MTKTEMPLATE	005

Aino	MTKTEMPLATE	F69, F89
Aio	MTKTEMPLATE	N97
AirFone	MTKTEMPLATE	AF111
Airphone	MTKTEMPLATE	No1, No4
Airtel	MTKTEMPLATE	L900
Ajanta	MTKTEMPLATE	A3000, A4200, A5000, A52
Alcatel Virgin	MTKTEMPLATE	VM202, VM363, VM621i, VM800
Alcatel	MTKTEMPLATE	One Touch OT-090, One Touch OT-103, One Touch OT-104, One Touch OT-106, One Touch OT-108, One Touch OT-109, One Touch OT-112, One Touch OT-113, One Touch OT-140, One Touch OT-150, One Touch OT-203, One Touch OT-203E, One Touch OT-204, One Touch OT-205, One Touch OT-206, One Touch OT-208, One Touch OT-209, One Touch OT-213, One Touch OT-214, One Touch OT-216, One Touch OT-222, One Touch OT-223, One Touch OT-250, One Touch OT-252, One Touch OT-255, One Touch OT-255D, One Touch OT-280, One Touch OT-300, One Touch OT-301, One Touch OT-303, One Touch OT-304, One Touch OT-305, One Touch OT-306, One Touch OT-311, One Touch OT-315, One Touch OT-315M, One Touch OT-355, One Touch OT-355D, One Touch OT-356, One Touch OT-360, One Touch OT-361,

		One Touch OT-362, One Touch OT-363, One Touch OT-380, One Touch OT-383, One Touch OT-385, One Touch OT-385J, One Touch OT-455, One Touch OT-505, One Touch OT-505K, One Touch OT-506, One Touch OT-506D, One Touch OT-508, One Touch OT-540, One Touch OT-543, One Touch OT-565, One Touch OT-565K, One Touch OT-585, One Touch OT-585D, One Touch OT-602, One Touch OT-602D, One Touch OT-606, One Touch OT-633, One Touch OT-660, One Touch OT-665, One Touch OT-706, One Touch OT-708, One Touch OT-710, One Touch OT-710D, One Touch OT-710K, One Touch OT-7110, One Touch OT-799, One Touch OT-800, One Touch OT-802, One Touch OT-802Y, One Touch OT-803, One Touch OT-803D, One Touch OT-806, One Touch OT-806D, One Touch OT-807, One Touch OT-807D, One Touch OT-808, One Touch OT-808M, One Touch OT-809, One Touch OT-813, One Touch OT-813D, One Touch OT-818, One Touch OT-818D, One Touch OT-819, One Touch OT-819D, One Touch OT-828, One Touch OT-880, One Touch OT-888,
--	--	---

		One Touch OT-888D, One Touch OT-900, One Touch OT-901, One Touch OT-905, One Touch OT-907, One Touch OT-AM01, One Touch OT-B331, One Touch OT-C700, One Touch OT-C701, One Touch OT-C707, One Touch OT-C717, One Touch OT-C819D, One Touch OT-EL05, One Touch OT-F0Z9, One Touch OT-F115, One Touch OT-F121, One Touch OT-F122, One Touch OT-F152, One Touch OT-F330, One Touch OT-F331, One Touch OT-F344, One Touch OT-I606, One Touch OT-I650, One Touch OT-I780, One Touch OT-I802, One Touch OT-I808, One Touch OT-I818, One Touch OT-I880, One Touch OT-I888, One Touch OT-I898, One Touch OT-I905, One Touch OT-KR01, One Touch OT-M298, One Touch OT-MD01, One Touch OT-MD02, One Touch OT-MS01, One Touch OT-MS02, One Touch OT-Q3, One Touch OT-S122, One Touch OT-S215, One Touch OT-S218, One Touch OT-S319, One Touch OT-S320, One Touch OT-S321, One Touch OT-S520, One Touch OT-S521, One Touch OT-S621, One Touch OT-S626, One Touch OT-T208, One Touch OT-T218, One Touch OT-T255, One Touch OT-T355,
--	--	---

		One Touch OT-V345, One Touch OT-V350, One Touch OT-V354, One Touch OT-V355, One Touch OT-V555, One Touch OT-V570, One Touch OT-V607, One Touch OT-V670, One Touch OT-V770
Alfatell	MTKTEMPLATE	C200, c500, H1, H1A, H2, H3, H300, H4, H5, H5A, H9
Allview	MTKTEMPLATE	S1, S2
Anoking	MTKTEMPLATE	M9
Anycall	MTKTEMPLATE	Cect-168, D900, F488E, i660, i908+, L708, S628
Anycoll	MTKTEMPLATE	A508, i908e, L588, QS850
Anycool	MTKTEMPLATE	D66, D66+, D66++, E307, E553, E556, E802, E880, E880C, E880L, E883, E888, F818, T808, T818
Anylink	MTKTEMPLATE	6500, N99i
Anyoall	MTKTEMPLATE	sgh-908i
Aobang	MTKTEMPLATE	A880
Aote	MTKTEMPLATE	M660
Appo	MTKTEMPLATE	A300
Aroma	MTKTEMPLATE	D333
Asus	MTKTEMPLATE	V75
Atan	MTKTEMPLATE	M760
AT-Telecom	MTKTEMPLATE	Hi-Messenger
Aura	MTKTEMPLATE	s902, S908
Auro	MTKTEMPLATE	6321
Austar	MTKTEMPLATE	F455+
Avio	MTKTEMPLATE	A101, A102, A201, A203, A204, A205, A301, A403, A6103
Avvio	MTKTEMPLATE	209, 409, 505, 530A, 930A, A1000, GD852p
Awang	MTKTEMPLATE	A828
A-zed	MTKTEMPLATE	z62
Azumi	MTKTEMPLATE	Bird D515, D615, D706, F1, F501, F518, K102, K298, M3, Q503, S101,

		S230, S302, S305, S306, S710, V708, V750, V788, V789
Baizhao	MTKTEMPLATE	S8958, S8978, TV488
Baoxing	MTKTEMPLATE	K700, K900, N1000
Barbie	MTKTEMPLATE	P520
Basicom	MTKTEMPLATE	V9
BBC	MTKTEMPLATE	i508
BBK	MTKTEMPLATE	i2288, K202, K300, S201, S202
Beetel	MTKTEMPLATE	EC003, ev530
BenQ	MTKTEMPLATE	A53, C30, C36
Bess	MTKTEMPLATE	SP500, VZ210, VZ219
Bestel	MTKTEMPLATE	D5000+, D600, D6000, D7000+, E71TV
Bestking	MTKTEMPLATE	A2688
Bestone	MTKTEMPLATE	KA08+
Betels	MTKTEMPLATE	6000+
Beyond	MTKTEMPLATE	B333, B38, B505, B530, B818, B83, BY125, C3
Bilwani	MTKTEMPLATE	B2, B3, B9
Bird	MTKTEMPLATE	D515, D615, D706, F501, F518, K102, K298, S230, S302, S305, S306, S710, V708, V750, V788, V789
BlackCherry	MTKTEMPLATE	BL1000, bl2000, BL7000B, BL8000
Blacklable	MTKTEMPLATE	VVV363
Bleu	MTKTEMPLATE	255x, 354x, 355x, 453x, 454x, 456x, 466x, 471x, 476x, 551x, 555x, 670x
Bliss	MTKTEMPLATE	D108, D208, V98
Blu	MTKTEMPLATE	Q200, Q200e
Bluebo	MTKTEMPLATE	Hi5
BMobile	MTKTEMPLATE	C628, K298, TV9, X131
BMW	MTKTEMPLATE	760i, X6
Bonmi	MTKTEMPLATE	222, f430+
Boostwer	MTKTEMPLATE	E66
Bossh	MTKTEMPLATE	B70, D112, D96M
Bost-Mobile	MTKTEMPLATE	D615

Bugatti	MTKTEMPLATE	164, HOOD
Buss	MTKTEMPLATE	G618
Byond	MTKTEMPLATE	By-400, BY-888, BY-999
Bytone	MTKTEMPLATE	T3
Capitel	MTKTEMPLATE	P600
Carbon	MTKTEMPLATE	Art
Cartier	MTKTEMPLATE	V8
Cavio	MTKTEMPLATE	ZT-618, ZTF1
CayenneS	MTKTEMPLATE	Z9
CCK	MTKTEMPLATE	E7
Cect	MTKTEMPLATE	003, 1088, 199, 5800D, 599, 605, 6300L, 808, 888, A008, A100, A1818, A519, A6668, A706, C2000D, C3000, C3600s, C5188, C600, C800, C828, C8600, C92+, E900, F1200, F22, i658, IP200, K2, K369, k770, K808, K808+, K828, K838, LV918, M619, M8, M8600, N6298, N73, N788, N81+, N82, P168, P3711, P3711i, P8400, Q380, Q500, Q500BT, Q558, Q618, Q638, Q8, Q86, S588, S613, S800, S90, S901, T1, T118, T520, t590, T601, T689, T808, T918, T999, U880, U8810, U90, V180, V200, V329, V400, V6688, V668B, V70, V768, V777, V90, V909, V98, Y200, Y809
CellOne	MTKTEMPLATE	CX900
Century	MTKTEMPLATE	Pioneer-B889+
Cert	MTKTEMPLATE	V400
Cesim	MTKTEMPLATE	A35, A510, A9530, CG400, N88, N97, V130, V30, V310, V470, V590, V709, V800, V800i, V88, V950
Changhong	MTKTEMPLATE	A330, K218, L138, M838
Changjiang	MTKTEMPLATE	A968, N8+
Changxing	MTKTEMPLATE	A868
ChatPhone	MTKTEMPLATE	SN50

Cherry	MTKTEMPLATE	YC8
Cherry-Mobile	MTKTEMPLATE	D15, D20, Q61
CherryMobile	MTKTEMPLATE	Q4Duo
Cherry-Mobile	MTKTEMPLATE	D15, D20, Q61
ChinaStar	MTKTEMPLATE	C507
Cinte	MTKTEMPLATE	4G+++ , 9000C, 911, V902, 9650 WIFI, a008, A1 watch phone, A3 Mini TV mobile phone, A750, A808 watch phone, A810watch phone, A820 watch phone, A9530 N9 Mini TV, Aoke08 watch phone, Aoke09 watch phone, C1000, c5, c5000, c6, Compass 4GS, E73, EG110 watch phone, EG120 watch phone, eg200, F003, F006, F3 watch phone, FM5000, G555 watch phone, G700, GD910, H003+, H003TV, H1, H109 TV, H4000, H802D, H9, H9590, i4GS+, i66, I68 4G, i9, J2000, J8, JC E9, JC37, JC9700+, K1 watch phone, KA09, Ki4, M002L, M810 watch phone, M860, MQ006, MQ008, MW08, N200+, N388, N800, NO.4, P168i 3GS, Q7, Q8, qmini cck10, T5000, T6000, T8100, V8, W009+, W08, W09, W600, W688, W88, W968, WG3, X7+
CKing	MTKTEMPLATE	K339
Club	MTKTEMPLATE	C900
cNokia	MTKTEMPLATE	E71TV, TVE71
Coby	MTKTEMPLATE	MP777
Cool	MTKTEMPLATE	ATL-V8
Coral	MTKTEMPLATE	255, 280, 450, 550, 620, 640, 655, 680
Corby	MTKTEMPLATE	L6, W6233
Cosun	MTKTEMPLATE	289, 638, 8988, 9958

Crew	MTKTEMPLATE	202
C-Right	MTKTEMPLATE	C10, L2000
Cross	MTKTEMPLATE	CB65, CB90, CB97, G10, GG53, GG53B, GG55, GG71, V4
Crtel	MTKTEMPLATE	C200
CSL	MTKTEMPLATE	C9900, DS110, i200
cvfd	MTKTEMPLATE	m31
CXTel	MTKTEMPLATE	D90
Cyfon	MTKTEMPLATE	C800i
Cynix	MTKTEMPLATE	D28
Dapeng	MTKTEMPLATE	T2000, T3000, T5000, T928
Daxian	MTKTEMPLATE	529, 619, 669, 780, 8100, C800, C8100, E689, J168, J6, JT398, K888, KT1, N55, N800, P168, T108, X3000, X728, X9188, X960, X999
DBest	MTKTEMPLATE	Royal-VT888
Deco	MTKTEMPLATE	F1
Delta	MTKTEMPLATE	X200
Desay	MTKTEMPLATE	K618, L608, M535
Dezzo	MTKTEMPLATE	D800
Diadem	MTKTEMPLATE	MK901, ML718, ML722, ML780, ML825, MO650, MT808, MT809, MT810
Diamond	MTKTEMPLATE	A1000, B711
Diga-Mobile	MTKTEMPLATE	D122, G123, G126
Digga	MTKTEMPLATE	D25
Digiphone	MTKTEMPLATE	9800TV
Dirland	MTKTEMPLATE	M881, R100
Disney	MTKTEMPLATE	520+
DMND	MTKTEMPLATE	W720i
D-One	MTKTEMPLATE	DG518, DG568, DG817, G628
Donod	MTKTEMPLATE	D505, D5130, D805, D806, N95i
Doov	MTKTEMPLATE	YH923
Dopod	MTKTEMPLATE	A6188, E61+, M500TV, S560

Dopodo	MTKTEMPLATE	E61+
Dorado	MTKTEMPLATE	A006, C5000, D380, D890, T33i, TV15
Doro	MTKTEMPLATE	338GSM, HandleEasy-328gsm, HandleEasy-345gsm, HandleEasy-409s, HandleEasy-410s
Dotcom	MTKTEMPLATE	MB-2300TV
DRV_Mobiles	MTKTEMPLATE	R52
Dubao	MTKTEMPLATE	738, 758, 768, 777
DV-Phone	MTKTEMPLATE	V93i
Eagle	MTKTEMPLATE	E52
Egitel	MTKTEMPLATE	V6
Egtel	MTKTEMPLATE	V7
Eiroga	MTKTEMPLATE	E666
Ektel	MTKTEMPLATE	C1-TV
Elenberg	MTKTEMPLATE	MT520
Elgin	MTKTEMPLATE	EL-MP730
Elitek	MTKTEMPLATE	FN8618
Elitex	MTKTEMPLATE	8888
Enimac	MTKTEMPLATE	MQ8200
Enmac	MTKTEMPLATE	MQ3300, MQ8200
Epoda	MTKTEMPLATE	EP2502
Eriwin	MTKTEMPLATE	ZX-A1, ZX-A8500, ZX-AM01, ZX-C6000, ZX-C700, ZX-E33, ZX-ET-2, ZX-F116, ZX-F52, ZX-F605, ZX-F668, ZX-FX3, ZX-FX8, ZX-i6 pro, ZX-L900, ZX-N700, ZX-Q10, ZX-Q1000, ZX-Q88, ZX-Q89, ZX-QY003, ZX-T001, ZX-T8100, ZX-W1, ZX-W102, ZX-W105, ZX-Y005, ZX-Y008, ZX-Y009, ZX-Y010
Etisalat	MTKTEMPLATE	211FM
E-Top	MTKTEMPLATE	S30
ETouch	MTKTEMPLATE	232Pro, 303Pro, 515Pro, 616Pro, 636Pro, CG1, D108, D11, D12, D120, D160, D18, D200, D21, D220, D23, D30, D300,

		D33, D35, D38, D6, D60, DS100, F50, J100, J165, J168, MD82, X88i, XL10, XL25, XL53
Everfo	MTKTEMPLATE	2456, 2461, 2601, 2602, 3008, E2211+, E7110, E711D TV, E713D, E730
Evertex	MTKTEMPLATE	E300, X90
Evolve	MTKTEMPLATE	GX607
Eyo	MTKTEMPLATE	E71, E71s
Fashion	MTKTEMPLATE	A5688, F023, F025, T508, T588
Ferrari	MTKTEMPLATE	267v, Ascent, F1, F100, F108, F9, RHV3
FixedPhone	MTKTEMPLATE	FC8050
FixMobile	MTKTEMPLATE	A969
Fly	MTKTEMPLATE	2040i, 2040L, 2080, B600, DS100, DS105, DS110, DS110i, DS150, DS155, DS156, DS160, DS165, DS170, DS180, DS185, DS210, DS400, E130, E135, E140, E145, E147TV, E160, E170, E171, E175, E181, E185, E190, Ezzy, G1, Hi-SLDR, M130, M140, MC105, MC120, MC130, MC150DS, MC160, MC165, MC170DS, MC175, MC180, MC220, MC300, MP500, MP600, MX230, MX300, Q110, Q200, Q300, Q400, Q410, Q420, SL110, SL130, SL140DS, SL140i, SL399E, SL500i, SX200, SX205, SX230, SX300, SX305, SX315, V100, V180DS, X60
Flying	MTKTEMPLATE	F007, F035, F69, F800, F900, F916, F936, F996
Flynet	MTKTEMPLATE	F001
Fly-Ying	MTKTEMPLATE	E71, E71i, F003, F006, F007, F008, F021, F026, F030, F035, F036, F080, F200, F636, F698, F99

FMobile	MTKTEMPLATE	B290
Fome	MTKTEMPLATE	N7
Forby	MTKTEMPLATE	G899
Forme	MTKTEMPLATE	6303, D386, D5, E71, F8, F8+, F808, F9, L300, M6, M800, N26, N78, N82, U969
Fory	MTKTEMPLATE	F288
Foston	MTKTEMPLATE	968B, FS-829, FS-836B, FS-862, FS-868B, FS-889, FS-968, FS-968A, FS-968B
Frost	MTKTEMPLATE	701, F27, M23
FUCHEN	MTKTEMPLATE	FCB083, FCB092, FCD11, FCV11 DVB-T, i5000 MT6253 GPRS TV J AVA, i5000, MT6253, PDA8915
Fuchen	MTKTEMPLATE	PDA8915 MTK 6236
FUCHEN	MTKTEMPLATE	FCB083, FCB092, FCD11, FCV11 DVB-T, i5000 MT6253 GPRS TV J AVA, i5000, MT6253, PDA8915
Fujistar	MTKTEMPLATE	FJ-71
Funker	MTKTEMPLATE	F803DS
Funny	MTKTEMPLATE	A8, Mobile V20
G+G	MTKTEMPLATE	i908
Galaxy	MTKTEMPLATE	T81
Gaoxinqi	MTKTEMPLATE	GXQ-F896, GXQ-H69, N82, TL528
Genx	MTKTEMPLATE	T-Z8
Getek	MTKTEMPLATE	TK806
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808,

		U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8,

		G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9

		T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9

		N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160,

		C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9
GFive	MTKTEMPLATE	6620, 7610, D902, E71, L700, M73, N79, N79i, T33+, T580, U800, U808, X9
G-Five	MTKTEMPLATE	3120, 3510, 6620, 736, 7610, 7630, 800, C2160, C6233, D11, D60, D68, D70, D90, D902, D99, E71y, e82i, F2, F3, F7, F8, G3000, G365, G370, GF18, GF73, H600, H91, i300, i310, L300, L700, M1, M33, M5130, M6, M7, M73, M77, M99, N79, N79i, N90, Q33, S9, T320i, T33, T33+, T580, U303, U505, U717, U800, U808, U828, U855, U879, U899, U909, U939, U969, X9

		U909, U939, U969, X9
G-Fone	MTKTEMPLATE	301, 311, 411, 422
Gibox	MTKTEMPLATE	MK396, MK397
Gild	MTKTEMPLATE	6700, FXD3600, H1, N9, S648, S76, S93, X5
Ginzzu	MTKTEMPLATE	R6 Ultimate
Gionee	MTKTEMPLATE	A10-TV, E99, I9, L7, MediaMobile, V890
Gjiang	MTKTEMPLATE	W007
Glid	MTKTEMPLATE	6700
Globul	MTKTEMPLATE	TA2322n
G-Mobile	MTKTEMPLATE	N82
GMobile	MTKTEMPLATE	T68
Gnet	MTKTEMPLATE	G8600
G-Right	MTKTEMPLATE	6700, 6700i, 6800, C200, E52, G2, L200, L300, L400, L600, U808, U999, V400, X400
Haier	MTKTEMPLATE	G111, HG-A8, HG-V70, M300, M306, M307, M500, S210, Z701S, Z702
Hantel	MTKTEMPLATE	A800, bl699, D801, H5, HT6600, m2210, M678, TV-488
hengda	MTKTEMPLATE	8520, 9600, 9790, c9000, mini 9800, q10, Q5, Q8
ht6088	MTKTEMPLATE	ht6088
HTC (fake)	MTKTEMPLATE	W010
HTC fake	MTKTEMPLATE	6262, A288, G1-TV90, Hero-G3, S900
Huawei	MTKTEMPLATE	G20, G3500, G3501, G3510, G3510m, G3510s, G3610, G5010, G5500, G5730, G5760, G5760s, G6, G6005, G6150, G6150a, G6300, G6600, G6603, G6608, G660D, G6610, G6610v, G6620, G7002, G7007, G7010, G7050, G7105, G7206, G7210, G7300, G7600, T330, T710, T711
Huayu	MTKTEMPLATE	A3, CM336, G688, K878, K888, L888, M678, M818

Imobile	MTKTEMPLATE	2211, 222, 318, 320, 360, 510, 511, 516, 520, 523, 530, 610, 630, CE0889, IE3210
Intex	MTKTEMPLATE	IN1212, IN1224, IN2010, IN2020E, IN2020QT, IN2022, IN2030, IN2030D, IN2030DX, IN2040E, IN2040N, IN2044, IN2080, IN2080E, IN2222, IN2233, IN2244, IN2266, IN3030, IN3055, IN3060, IN3070, IN3080, IN3333, IN4040, IN4060, IN4415, IN4420, IN4420S, IN4455, IN4460, IN4466, IN4477, IN4488, IN4495, IN5030, IN5040, IN5050, IN5544, IN5555, IN6611, IN6633, iSmart
JinPeng	MTKTEMPLATE	007FM, 488, 5108, 5199, 5588, 768, 8283, A1280, A2198, A5120, A5616, A5658, A5688, A666, a799, A928, C3000, E55, E6180, E88, F8, H788, i908, JP1688, K330, K730, K989, L808, M8, M868, M99, S109, S1318, S1888, S2128, S868, V70, V70FM, W169, W880
JiXin	MTKTEMPLATE	J2000
Karamfone	MTKTEMPLATE	S4, X5
Karbons	MTKTEMPLATE	K10, K118, K217, K25, K300, K331, K334, K343, K350, K406, K443, K444, K444i, K445, K446, K450, K451, K460, K478, K496, K541, K550, K560, K570, K661, KC411
Kenuo	MTKTEMPLATE	D9, KN-76D, N750
Kenxindad	MTKTEMPLATE	300
Kiech	MTKTEMPLATE	N8899
Kifung	MTKTEMPLATE	S108
Kimcell	MTKTEMPLATE	N88
Kingdom	MTKTEMPLATE	K2
KingK	MTKTEMPLATE	800
King-One	MTKTEMPLATE	K608

Kingpo	MTKTEMPLATE	E320
Kingsun	MTKTEMPLATE	V902
Kinloong	MTKTEMPLATE	K288+
Kisen	MTKTEMPLATE	P83
Konka	MTKTEMPLATE	A76, A76FM, C623, D225, D620, D770, E303, G208
Kotka	MTKTEMPLATE	E90
K-Touch	MTKTEMPLATE	A5118, A615, A635, A905, A933, B830, b920, B922, D170, D700, D780, H777, H999, S515, V760, V908, V918
Kyocera	MTKTEMPLATE	C2500, E2500, E3500, S1600
Lava	MTKTEMPLATE	A10, A9, ARC02, KKT22, KKT24, KKT25, KKT30, KKT34, M23
Lenovo	MTKTEMPLATE	688, A330, A350, A539, BA20, BA21, BA22, BA23, CA10, CA12, CA13, E520, F10, i510, i60, i706, P50, P612, P618, P650, PA10, PA11, PA12, S533, S62, Shark32, Z-MK189
LG	MTKTEMPLATE	C193, C199, C205, C333, LG355, S310
Iphone	MTKTEMPLATE	AK8, C500
Mathron	MTKTEMPLATE	B2000, DH9860, T001, T006, T007, T010, T015, Y007, Y008, Y009
Maximus	MTKTEMPLATE	EX75, T44
Maxtel	MTKTEMPLATE	K94
Maxtel	MTKTEMPLATE	K48
Maxtron	MTKTEMPLATE	MG175, MG182, MG278
Mebaya	MTKTEMPLATE	A18
Mediatek	MTKTEMPLATE	G104 watch phone, MTK platform phone, One Touch OT-105, One Touch OT-600, T001, T006, v700, W510, W818, ZX-QY001, ZX-Y007
Megafon	MTKTEMPLATE	CP10, TDM15
Megatec	MTKTEMPLATE	Luxe

Megatek	MTKTEMPLATE	M100
Meidea	MTKTEMPLATE	E65, E66, Y100, Y1000, Y300, Y400, Y500
Melbon	MTKTEMPLATE	M2, MB-606m
Mercury	MTKTEMPLATE	Maestro, ST3
Message-phone	MTKTEMPLATE	QS150
Metfone	MTKTEMPLATE	Closer
Metom	MTKTEMPLATE	M20, M20IV, M20TV, M28, M29, M39, MT309, N11, N81, N82, T300
Mex	MTKTEMPLATE	MX14BS, N95
MFU	MTKTEMPLATE	6700, M6
Mi	MTKTEMPLATE	200
Micro	MTKTEMPLATE	M11
Micromax	MTKTEMPLATE	GC255, M2, Q1, Q1+, Q2, Q3, Q5, Q50, Q55, Q6, Q7, Q75, Q80, X112, X113, X114, X115, X116, X117, X118, X122, X1i, X1i+, X1u, X200, X211, X212, X215, X220, X225, X226, X228, X230, X235, X250, X260, X262, X263, X265, X266, X280, X285, X2i, X2i+, X310, X330, X332, X360, X361, X370, X395, X414, X450, X485, X50, X505, X510, X555, X560, X600
Micxon	MTKTEMPLATE	MTV800
Mito	MTKTEMPLATE	1868, 288GG, 302
Mixcon	MTKTEMPLATE	S908
Mobiado	MTKTEMPLATE	105
Mobistel	MTKTEMPLATE	EL350
Modelabs	MTKTEMPLATE	Elite, MyWay-Slim, V- Touch
Moille	MTKTEMPLATE	ZTC-ZT588
Mojo	MTKTEMPLATE	Chat
Momentum	MTKTEMPLATE	M35
Moses	MTKTEMPLATE	V670
Motorcla	MTKTEMPLATE	T628, V80
Motorola	MTKTEMPLATE	EX108, EX109, EX112, EX115, EX118, EX119,

		EX122, EX126, EX128, EX211, EX212, EX223, EX245, EX292, WX160, WX161, WX180, WX181, WX260, WX265, WX280, WX288, WX290, WX295, WX306, WX345, WX390, WX395
MoviePhone	MTKTEMPLATE	FA6
Mox	MTKTEMPLATE	MO698, MO800, MO875
MPEG4	MTKTEMPLATE	NP68, T698
MPmobile	MTKTEMPLATE	M02
MTV	MTKTEMPLATE	800, N73
Much	MTKTEMPLATE	DS-850
Muzak	MTKTEMPLATE	N88
MVL	MTKTEMPLATE	G81
MyPhone	MTKTEMPLATE	1070, 3350, 3370, 6650, 6651, 6670, 6691, B21, B21c, B22, B23, B50, B50c, B71, Q19, Q21, Q22, Q88, QT7, S21, T12, T13, T22, T23, T52
Narnia	MTKTEMPLATE	8088, i70, V6
Nasaki	MTKTEMPLATE	B9, G5, NK630
Nckia	MTKTEMPLATE	5610, 5700, 5700+, 6300c, C5, E71, M9, N10+, N99i, XpressMusic
Neccom	MTKTEMPLATE	n880+
Neoi	MTKTEMPLATE	809
Newrone	MTKTEMPLATE	i8
Newtone	MTKTEMPLATE	NTi8, Q6
Nexcel	MTKTEMPLATE	E71
Nexcom	MTKTEMPLATE	NC328
Nexian	MTKTEMPLATE	NX-G381i, NX-G503, NX-G505, NX-G522, NX-G700, NX-G788, NX-G801, NX-G868, NX-G900, NX-G901, NX-G911, NX-G922, NX-G923, NX-T780, NX-T900, NX-T911
NJStar	MTKTEMPLATE	L1100
Nkiac	MTKTEMPLATE	F168

Nktel	MTKTEMPLATE	2800, 300, 5310, A100, A200, A300, A500, A600, A700, A8800, A8800+, C2000, C2008, C5000, C6000, C7000, C8000, C8600, C9000, E71, K100, K200, K300, K400, K770, K99, S350, U800
Nokig	MTKTEMPLATE	N97
Nokla	MTKTEMPLATE	6500s, 9000+, C7i, D328, E90, N72, N77, N95, N958, N96, N97
Nony	MTKTEMPLATE	E71, E71+, S208, S212, S311, S332
Nova	MTKTEMPLATE	N800
Novo	MTKTEMPLATE	ST200
Olive	MTKTEMPLATE	VG200, VG300, VG3000, VG3100, VG3200, VG3201, VG400, VG500, VG800, VGc800
Onida	MTKTEMPLATE	C628, F830, G610, V110, V115, W1110, W1410
Orion	MTKTEMPLATE	810, 900DS, 903, 910DS
Pantech	MTKTEMPLATE	C180, C320, P1010
Philips	MTKTEMPLATE	199, 292, 298, 390, E100, E210, F322, F511, K700, M200, X100, X116, X216, X223, X312, X325, X501, X503, X518, X519, X703, X710, X806, X860
PowerPack	MTKTEMPLATE	TC-2GSM_E553, TCG-8801, TCG-8888, TCGS-218, TCGS-8806, TCGS-8818, TCTV-158, TCTV-178, TCTV-228, TCTV-278, TCTV-438
QMobile	MTKTEMPLATE	E125, E150, E195, E200, E400, E500, E900, F22, F220, F23, F252, F55, F680, M2, M22, ME114, Q11, Q126, Q18, Q180, Q20, Q21, Q212, Q213, Q218, Q24, Q25, Q25i, Q26, Q266, Q26i, Q27, Q28, Q28i, Q29, Q33, Q37, Q38, Q3i, Q4, Q510, Q5310, Q55, Q61, Q63,

		Q66, Q73, Q8, Q88, Q99, T550, T630
Rocker	MTKTEMPLATE	Crazy, Dream, R111, RX15, Scorby
Rolex	MTKTEMPLATE	HK010, K8, K9, MU100
Royal	MTKTEMPLATE	S3588, VT888, VX
Samkung	MTKTEMPLATE	TV16
Samsking	MTKTEMPLATE	V11
Samsung	MTKTEMPLATE	E318
Samsonic	MTKTEMPLATE	U800+
Sands	MTKTEMPLATE	A203, A303i, P908
ScellPhone	MTKTEMPLATE	e688, i68, i68+, i68++, i69, i9+++ , i99++, L88, Q11, s18, tv1000
Sigmatel	MTKTEMPLATE	3600i, 5130, 6700, 7700, 9300, FXS S83, Ginwave25, H1, Hxd3600, N9, S18, S18i, S22, S3, S30, S3plus, S4, S400, S47, S66, S77, S80, S80i, S81, S86, S88 s90 s98, S9, S90, S9000, S90i, S91, S96, T2, T300, t33+, T33i, T55, T66, T85, T99, T99i, TV60, V88, W999
Simoco	MTKTEMPLATE	SM1000, SM1100, SM1200, SM234, SM399, SM498, SM499, SM611, SM633, SM988, SM999
Spice	MTKTEMPLATE	D80, D88, D88N, D90, M3636, M4242, M4250, M4580, M4580n, M5050, M5055, M5151, M5161, M5252, M5454, M6000, M6060, M6262, M6363, M940, QT44, QT50, QT52, QT55, QT58, S300, S5110, S5330, S570, S580, S590, S650, S7, S700, S7000, S705, S707, S707N, S710, S808, S820
Storm	MTKTEMPLATE	F9500
Suny-ericssom	MTKTEMPLATE	W558
Symphony	MTKTEMPLATE	C100, CKT23C, CRAB-S3, D40, D45, D65, EX85

T6800	MTKTEMPLATE	T6800
TCL	MTKTEMPLATE	T106
Tecall	MTKTEMPLATE	T200, T300
Techno	MTKTEMPLATE	T220, T670, X780i
Tecno	MTKTEMPLATE	D100, T330, T600, T800, V410, V500, V801
Tecnoshow	MTKTEMPLATE	TC8898
Telego	MTKTEMPLATE	V808
TengYu	MTKTEMPLATE	N86, N98+
Tethin	MTKTEMPLATE	S350
Tian-Wai	MTKTEMPLATE	T3
Tianxin	MTKTEMPLATE	H003, H003+
Tiger	MTKTEMPLATE	7710, 7736
Tinno	MTKTEMPLATE	E01c, HD100, T670, TV900
Tintele	MTKTEMPLATE	s2, TT-N1_Black, TT-N1_Gold, TT-V2, TT-V300, TT-V33
Titan	MTKTEMPLATE	V71
T-Mobile	MTKTEMPLATE	Energy
Tocs	MTKTEMPLATE	C001, M52
Tomsim	MTKTEMPLATE	C90E
Tonga	MTKTEMPLATE	M108
Toptop	MTKTEMPLATE	T22
Tosello	MTKTEMPLATE	Spatola
Toshibo	MTKTEMPLATE	Q300, V118, V9+, V9++
TouchPhone	MTKTEMPLATE	i9
Trend	MTKTEMPLATE	T200, T786
Trident	MTKTEMPLATE	MB-1100, MB-E55, W-T8
TTK	MTKTEMPLATE	N81, N82
TV-Mobile	MTKTEMPLATE	2sim, 8800, A2688, A968, Ak09, C902, E71, G10, K900+, N99i, S2, STD25, U26, V6, WiFi-C5000
Tvmobile	MTKTEMPLATE	C702, E71pro, Q1, T2010, X10
TV-Mobile	MTKTEMPLATE	2sim, 8800, A2688, A968, Ak09, C902, E71, G10, K900+, N99i, S2, STD25, U26, V6, WiFi-C5000

Tvmobile	MTKTEMPLATE	C702, E71pro, Q1, T2010, X10
TV-Mobile	MTKTEMPLATE	2sim, 8800, A2688, A968, Ak09, C902, E71, G10, K900+, N99i, S2, STD25, U26, V6, WiFi-C5000
Tvmobile	MTKTEMPLATE	C702, E71pro, Q1, T2010, X10
TV-Mobile	MTKTEMPLATE	2sim, 8800, A2688, A968, Ak09, C902, E71, G10, K900+, N99i, S2, STD25, U26, V6, WiFi-C5000
Tvmobile	MTKTEMPLATE	C702, E71pro, Q1, T2010, X10
TV-Mobile	MTKTEMPLATE	2sim, 8800, A2688, A968, Ak09, C902, E71, G10, K900+, N99i, S2, STD25, U26, V6, WiFi-C5000
Tvmobile	MTKTEMPLATE	C702, E71pro, Q1, T2010, X10
Twee	MTKTEMPLATE	A579, St88
TwinSim	MTKTEMPLATE	T60, T99
Ufo	MTKTEMPLATE	833, 995, Digital Mobile
Ufone	MTKTEMPLATE	G3510
Ultra-Slim	MTKTEMPLATE	M9
Upptel	MTKTEMPLATE	V700
UP-Tec	MTKTEMPLATE	TV-Mobile
Usha-Lexus	MTKTEMPLATE	838B, 877B
Utstarcom - Claro Nicaragua	MTKTEMPLATE	UT 114, UT 1258, UT 1261, UT 129, UT 198, UT GTX212
UTStartcom	MTKTEMPLATE	CFM114CP, CL1135, CLP138, CLX100PR, GLPF1114MX, GLPL148SV, GPF1134CA, GPF198, GPFE1238, GPFE128en, GPT2085, GPT380EN, GTX212, TE1201sv, TTX28MX
Vaic	MTKTEMPLATE	A1900, A618, E588, Strike TV-Mobile
Vaio	MTKTEMPLATE	A328, A968, T6
Vave	MTKTEMPLATE	S70
Vcall	MTKTEMPLATE	v329, V850

Vemo	MTKTEMPLATE	K630i
Venus	MTKTEMPLATE	C9000, S90, V300, V800, V900
Verycool	MTKTEMPLATE	i115, i119, i300, i305, i315, i405, i410, i500, i600, i720
Victor	MTKTEMPLATE	VM09, VM13, VM-15, VM-16, VM-92, VM-93
Videocon	MTKTEMPLATE	V1301, V1305, V1310, V1403, V1420, V1604
Vitell	MTKTEMPLATE	V222, V708, V717, V720
Vodafone	MTKTEMPLATE	135, 150, 235, 250, 252, 331, 340, 345, 351, 455, 541, 543, 547, 555
Wellcom	MTKTEMPLATE	W350, W819, W930, W9339
Xksstel	MTKTEMPLATE	S4, S4-FM, X1, X11, X12, X200, X400
XTelecom	MTKTEMPLATE	X3128, X9128, x9138, X918, X9199
Y500	MTKTEMPLATE	Y500
YOYI	MTKTEMPLATE	T007, T012, T015
Zhongzheng	MTKTEMPLATE	G300
ZOHO	MTKTEMPLATE	G500, W301, W302, W302D
Zonda	MTKTEMPLATE	1075, 1085, 1090, 1095, 1095R, 1098, 1099, TF350, TF425, ZMCK865, ZMCK870, ZMEM1120, ZMKN110, ZMTFTTV20, ZMTN600, ZMTN610, ZMTN615, ZMTN815, ZMTN905, ZMUR300